

429RTx & Discrete **Software Tools**

Programmer's Reference



Copyright © 2001–2025 Excalibur Systems. All Rights Reserved.

Table of Contents

1	Introduction	
	Overview	1-2
	Getting Started	1-2
	Installation	1-2
	Assigning a Device Number	1-3
	An Overview of the 429RTx Data Communications Bus	1-3
	Time Tag Word Formats	1-5
	Standard 32-bit Time Tag Format	1-5
	IRIG B Time Tag Format	1-6
	Discrete Channels	1-6
	429RTx & Discrete Software Tools for Modules on a Carrier Board	1-7
	Compiler Options	1-7
	Direct Memory Access (DMA)	1-8
	Conventions Used in This Manual	1-8
	Technical Support	1-8
2	General Functions	
	Get_DmaAvailable_RTx	2-2
	Get_Error_String_RTx	2-2
	Get_Time_Tag_RTx	2-3
	Get_UseDmalfAvailable_RTx	2-3
	Init_Module_RTx	2-4
	Read_Board_Intr_Status_RTx	2-7
	Read_Board_Status_RTx	2-7
	Read_Chan_Config_Register_RTx	2-8
	Read_Chan_Config_Stat_RTx	2-9
	Read_Global_Start_RTx	2-9
	Read_HwRevision_RTx	2-10
	Read_Number_Of_Channels_RTx	2-10
	Read_Revision_RTx	2-10
	Read_SerialNumber_RTx	2-11
	Release_Module_RTx	2-11
	Reset_Channel_Configuration_RTx	2-12
	Reset_Ttag_RTx	2-13
	Set_IRIG_Timetag_Mode_RTx	2-13
	Set_Prog_Bit_Rate_RTx	2-14
	Set_UseDmalfAvailable_RTx	2-15
	Start_Selected_Channels_RTx	2-16
	Start_Channel_RTx	2-17
	Stop_Channel_RTx	2-17
	Stop_Selected_Channels_RTx	2-18
	Using Interrupts Under Windows	2-19
	Get_Interrupt_Count_RTx	2-20
	InitializeInterrupt_RTx	2-20
	Wait_For_Interrupt_RTx	2-21
	Wait_For_Multiple_Interrupts_RTx	2-22

Using Interrupts Under VISA for VME Carrier Boards	2-23
--	------

3 ARINC 429 Receive Channels Functions

Receive Channel Overview.....	3-2
Memory Usage Limits	3-2
Receive Channel Setup.....	3-3
General Receive Functions	3-5
Set_Global_Storage_Mode_RTxx.....	3-5
Setup_Receive_Channel_RTxx	3-6
Translation Functions.....	3-8
Add_Translation_Entry_RTxx	3-8
Alter_Translation_Entry_RTxx	3-10
Enable_Translation_Table_RTxx	3-12
Map_Label_To_Translation_Entry_RTxx.....	3-13
Standard Storage Mode and Data Only Storage Mode Functions.....	3-14
Clear_Rcv_Word_Count_RTxx	3-14
Clear_Rcvd_Error_Cnt_RTxx.....	3-14
Enable_Filter_Table_RTxx.....	3-15
Read_Channel_Status_RTxx.....	3-16
Read_Next_Data_IRIG_RTxx	3-17
Read_Next_Data_RTxx	3-18
Read_Rcvd_Error_Cnt_RTxx.....	3-19
Read_Rcvd_Data_Word_Cnt_RTxx	3-19
Readback_Filter_Entry_RTxx	3-20
Set_Filter_Entry_RTxx	3-20
Set_Interrupt_Cond_RTxx.....	3-21
Set_Label_Trigger_RTxx	3-22
Set_Rcv_Interval_Trig_RTxx	3-22
Set_Rcv_Word_Cnt_Trig_RTxx	3-23
Set_Rcvd_Error_Cnt_RTxx.....	3-23
Set_Trigger_Cond_RTxx.....	3-24
Merge Storage Mode Functions.....	3-25
Clear_Merge_Word_Count_RTxx.....	3-25
Enable_Merge_Filter_Table_RTxx.....	3-25
Read_Merge_Error_Cnt_RTxx.....	3-26
Read_Merge_Rcvd_Word_Cnt_RTxx.....	3-26
Read_Merge_Status_RTxx.....	3-27
Read_Next_Merge_Data_IRIG_RTxx.....	3-28
Read_Next_Merge_Data_RTxx	3-29
Set_Merge_Interval_Trig_RTxx	3-30
Set_Merge_Intr_Cond_RTxx.....	3-30
Set_Merge_Label_Trigger_RTxx	3-31
Set_Merge_Trig_Cond_RTxx.....	3-31
Set_Merge_Word_Cnt_Trig_RTxx	3-32
Setup_Merge_Mode_RTxx	3-33
Look-up Table Storage Mode Functions.....	3-34
Enable_Lkup_Table_RTxx.....	3-34
Enter_Lkup_Entry_RTxx	3-35
Read_Lkup_Current_Lbl_RTxx.....	3-35
Read_Lkup_Data_RTxx	3-36

4	ARINC 429 Transmit Channels Functions	
	Transmit Channel Overview	4-2
	Transmit Channel Setup	4-4
	General Transmit Functions.....	4-6
	Allocate_Message_RTxx.....	4-6
	Load_FrequencyMessage_RTxx	4-7
	Load_Message_RTxx	4-9
	Read_Channel_Status_RTxx.....	4-11
	Read_Tx_Loop_Cnt_RTxx.....	4-12
	Read_Tx_Total_Words_Sent_RTxx.....	4-12
	Set_Interrupt_Cond_RTxx.....	4-13
	Set_Skip_Message_RTxx.....	4-14
	Set_Transmit_Loop_Counter_RTxx.....	4-15
	Set_Transmit_Message_Once_RTxx	4-16
	Set_Trigger_Cond_RTxx.....	4-17
	Setup_Frame_RTxx	4-18
	Setup_Transmit_Channel_RTxx	4-19
	FIFO Mode Functions.....	4-21
	Allocate_MAX_Transmit_FIFOs_RTxx	4-21
	Allocate_Transmit_FIFO_RTxx	4-22
	Load_Transmit_FIFO_RTxx.....	4-23
	Set_Transmit_FIFO_Size_RTxx	4-24
	Data Reconstructor Mode Functions	4-25
	Add_TTAG_Data_RTxx	4-25
	Setup_Ttag_Mode_RTxx	4-26
5	Discrete Channels Functions	
	Get_HWid_RTD.....	5-2
	Read_All_Input_Discretes_RTD.....	5-2
	Read_Input_Discrete_RTD	5-3
	Read_Output_Discrete_RTD.....	5-3
	Read_Pending_RTD	5-4
	Read_Pending_Register_RTD	5-4
	Reset_RTD.....	5-5
	Reset_Pending_RTD.....	5-5
	Reset_Pending_Register_RTD	5-6
	Set_Threshold_RTD.....	5-6
	Set_Trigger_RTD	5-7
	Set_Trigger_Destination_RTD	5-7
	Set_Trigger_Mask_RTD.....	5-8
	Set_Trigger_Value_RTD	5-9
	Start_Discrete_RTD	5-9
	Stop_Discrete_RTD.....	5-10
	Write_Output_Discrete_RTD.....	5-10

Appendix A	Data Configuration Returned by Read Data and Load Message Functions
Appendix B	<i>429RTx & Discrete Software Tools Library</i>
Appendix C	Code Index
Appendix D	Error Messages
Function Index	

1 Introduction

Chapter 1 provides an overview of the *429RTx & Discrete Software Tools*. The topics covered in this chapter are:

Overview	1-2
Getting Started	1-2
Installation	1-2
Assigning a Device Number	1-3
An Overview of the 429RTx Data Communications Bus	1-3
Time Tag Word Formats	1-5
Standard 32-bit Time Tag Format.....	1-5
IRIG B Time Tag Format	1-6
Discrete Channels.....	1-6
<i>429RTx & Discrete Software Tools</i> for Modules on a Carrier Board	1-7
Compiler Options	1-7
Direct Memory Access (DMA)	1-8
Conventions Used in This Manual.....	1-8
Technical Support.....	1-8

Overview

The *429RTx & Discrete Software Tools* is a set of ‘C’ language functions designed to aid users of Excalibur’s *429RTx[D]* cards, boards and modules to write test programs. These functions provide access to all of the *429RTx[D]* functions in a structured and straightforward programming environment.

429RTx & Discrete Software Tools is available for Windows and Linux. (See our website for additional software support.) The Windows functions were written and tested using Microsoft Visual C++.

Chapters 2 – 4 describe the functions, including syntax, flags and error messages, for the ARINC receive and transmit channels. Chapter 5 covers the functions unique to the Discrete channels on boards that have ARINC 429 and Discrete channels on the same module.

Note: The generic term *429RTx[D]* is used in the *Programmer’s Reference* to refer to all of the hardware items.

Getting Started

Before starting to write applications:

1. Install your board. For instructions, see **Installation Instructions.pdf** in the root folder of the *Excalibur Installation CD*.
2. Use the *Excalibur Installation CD* to install the software for your board and modules. For instructions, see **Installation Instructions.pdf**.
3. Locate the hardware manual (user’s manual) and the software manual (programmer’s reference) on the *Excalibur Installation CD*, for your board and modules.
4. Copy them to your computer.
5. Fill out the registration card and return it to your Excalibur representative.

Note: If anything is missing or damaged, contact your Excalibur representative.

Installation

For hardware and software installation instructions, see **Installation Instructions.pdf** in the root folder of the installation CD. When downloading new software from the Excalibur website, **Installation Instructions.pdf** is contained in the zip file.

The *Excalibur Installation CD* you received with your package is the most recent release of the CD as of the date of shipping. Software and documentation updates can be found and downloaded from our website: www.mil-1553.com.

The standard software provided with Excalibur boards and modules is for Windows operating systems. For more details, see **Installation Instructions.pdf**. Software for other operating systems may be available. Check on our website or write to excalibur@mil-1553.com.

Assigning a Device Number

ExcConfig is used to assign a device number of 0 – 15 to the board, which is used when running Excalibur's *Software Tools*. The first function generally called in an application program is `Init_Module`, and `Init_Module` requires the device number as one of its parameters.

ExcConfig assigns a device number by creating an association between the selected device number and the Unique Identifier of the board. It stores this information in the Windows Registry.

The Unique Identifier is set by a DIP switch or jumpers on the board. (For more details, see your board's user's manual. In the user's manual, the Unique Identifier is called the Selected ID.)

Note: When only one board of the same type is installed in your computer, you have the option of using the board's default device number instead of running ExcConfig. However, you cannot use the default device number when you have two or more boards in the computer that have the same default device number, or if your board does not have a default device number. The following table lists the default device numbers for most board types.

Board Type	Default Device Number	#define Value
UNET, RUNET, USB	None – the board's device number must be set via ExcConfig	N/A
VME	None – the board's device number must be set via a DIP switch (or jumper)	N/A
Ethernet, 664 (AFDX)	34 (dec)	EXC_ETHERNET_PCIE or EXC_664_PCIE
1394	32 (dec)	EXC_1394PCI
EXC-1553[c]PCI/MCH	29 (dec)	EXC_1553PCIMCH
All Other Current PCI[e] Boards (Including VPX and XMC)	25 (dec)	EXC_4000PCI

An Overview of the 429RTx Data Communications Bus

429RTx & Discrete Software Tools enables the user to create custom diagnostic programs for any of the *429RTx[D]* family of products. To apply *Software Tools*, some familiarity with the functioning of the multi-protocol, test and simulation *429RTx[D]* hardware is necessary and will assist in understanding the rationale of *Software Tools* functions.


For the additional functionality of the Discrete channels on modules that have both ARINC 429 and Discrete channels, see **Discrete Channels** on page 1-6 and **Discrete Channels Functions**.

Aeronautical Radio INC (ARINC) is an organization composed of major airlines and airplane manufacturers, which promotes standardization within aircraft equipment. To facilitate this end ARINC puts out specifications describing

communications busses as well as certain types of avionics systems. One of the more popular busses used in commercial aircraft today is the ARINC 429 bus. ARINC can be reached at www.ARINC.com.

ARINC 429 is a two wire differential bus, which can connect a single transmitter or source to one or more receivers or sinks. Two speeds are defined, 12.5 kHz and 100kHz. The ARINC specification defines not only the physical layer and electrical characteristics but the data format of data sent over the bus as well.

All data sent over the ARINC bus is composed of 32 bit words. While a number of different formats are used the following diagram is typical for ARINC 429 data.



Bits are transmitted starting with bit 1, the final bit transmitted is the parity bit which is implemented with odd parity. The label is transmitted with the most significant bit first while the data is transmitted least significant bit first.

The label is a value from 1 to 255 representing a particular type of data. Most labels are defined in the specification though some are reserved for future needs. Many labels are multiply defined in the specification based on the type of equipment being used.

The SDI field is used when a transmitter is connected to multiple receivers but not all data is meant to be used by all the receivers. In this case each receiver will be assigned an SDI value and will look only at labels which match its SDI value. While the specification calls for SDI 00 to be universally accepted, a good deal of equipment appears to disregard this requirement.

The Data field contains the actual data to be sent. A number of data formats are defined in the specification. Binary Coded Decimal (BCD) format uses each 4 bits to contain a single decimal digit. BNR data is a binary coding. For both data types the specification calls out the units, the resolution, the range, the number of bits used and how frequently the label should be sent. A Discrete type has multiple single bit fields defined within a single label. A number of other formats are described in the specification.

The SSM, which is 2 bits long [bits 30 and 31] when using BCD numeric Data Words or 3 bits long [bits 29 – 31] when using BNR numeric Data Words, interprets the numeric value in the data field. Examples of SSM values might be Plus, North, East, Right, To or Above.

P is the parity bit. ARINC 429 calls for odd parity. The parity bit is the last bit sent over the bus.

Time Tag Word Formats

The default Time Tag format is a standard 32-bit Time Tag. You have the option to use an IRIG B Time Tag instead, by calling `Set_IRIG_Timetag_Mode_RTxx`.

When using the standard 32-bit Time Tag, the function `Select_Time_Tag_Source_4000` sets the Time Tag source for all the modules on the carrier board. The Time Tag source cannot be set for individual modules. This function selects either the internal or external Time Tag. For more details on this function, see the *Excalibur Carrier Board Software Tools Programmer's Reference*.

Standard 32-bit Time Tag Format

When using the standard 32-bit Time Tag, the Time Tag is made up of two 16-bit Words: Time Tag-Hi and Time Tag-Lo. The Time Tag resolution is 10 microseconds.




Figure 1-1 Standard 32-bit Time Tag Format

IRIG B Time Tag Format

When using the IRIG B Time Tag, the Time Tag is made up of four 16-bit Words.




Figure 1-2 Time Tag Word Format in IRIG B Mode

The Updating from Internal Source bit indicates whether a valid IRIG B signal is being received by the module. When this bit is set to 1, the module is not receiving an IRIG B signal, and the module is updating the Time Tag based on its internal clock.

Discrete Channels

In addition to ARINC 429 modules, some boards have ARINC 429 and Discrete channels on the same module. Discrete input channels are user-selectable to TTL (0–5V) or Avionics (0–32V) voltage levels. Output channels are open collector, capable of handling up to 32V with a maximum sink current of 100 milliamperes each.

The Discrete channels contain control I/O registers that are memory mapped and can be accessed in realtime.

429RTx & Discrete Software Tools for Modules on a Carrier Board

There are numerous modules available for use on the EXC-4000/8000 family carrier board for various communications protocols.

Various combinations of these modules may be present on the board at one time. One application may access any of the following configurations:

- one module
- multiple modules of the same type located on one board
- multiple modules of the same type located on separate boards
- multiple modules of different types located on one or separate boards

A board level DLL accompanies the module for each of the boards and cards. Depending on the board, the names of the files are:

Carrier Board	DLL Name
VME and VXI	EXCV4000MS.DLL
All Other Boards/Cards	EXC4000MS.DLL

The functions that operate at the carrier board level are contained in the **EXC4000.c** file for PCI carrier boards and the **EXCV4000.c** file for VME/VXI boards. The function, `Get_4000Module_Type` may be called for each board and module number, to check which, if any, modules are currently available at that location. (This function is also called automatically from `Init_Module_RTx` to ascertain that the type of module is a *429RTx* module.) These DLLs are installed automatically in the Windows/System folder when the *429RTx & Discrete Software Tools* are installed for each of the boards/modules.

For more information on board level functions, see the *Programmer's Reference* for your carrier board. For other functions that operate at the carrier board level see the applicable hardware *User's Manual*.

Compiler Options

The DLL is compiled under Microsoft Visual studio using the `_cdecl` calling convention. The driver functions in the *429RTx & Discrete Software Tools* are supplied both in source form and linked as a DLL. When writing application programs, keep in mind that the module is a physical resource, and therefore you cannot run multiple copies of the program simultaneously.

Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for inputs where applicable.

Functions are written as 'C' functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_RTx` function. (**Appendix D: Error Messages**).

In Windows, all user-defined programs must include the file **proto_rtx.h**. (See **Appendix B: 429RTx & Discrete Software Tools Library**.) This file includes all the necessary header files and DLL function prototypes to operate *429RTx & Discrete Software Tools*.

Direct Memory Access (DMA)

Direct Memory Access (DMA) is available with PCI Express-based products. DMA enables the board, card or module to read from, or write to, system memory independently of the computer's CPU. This results in faster data transfer from the board, with much less CPU overhead than when not using DMA.

When DMA is available, the *429RTx & Discrete Software Tools Software Tools* use DMA access for functions that read from, or write to, memory.

The following functions use DMA:

Read_Next_Data_RTx
Read_Next_Merge_Data_RTx

Conventions Used in This Manual

The following conventions are used in this manual:

Functions look like this.

Variable types look like this.

Parameter look like this.

File names look like this.

FLAGS look like this.

Technical Support

Excalibur Systems is ready to assist you with any technical questions you may have. For technical support, visit the [Technical Support](#) page of our website (www.mil-1553.com). You can also contact us by phone. To find the location nearest you, visit to the [Contact Us](#) page of our website. Before contacting Technical Support, please see [Information Required for Technical Support](#).

2 General Functions

Chapter 2 describes software functions that are necessary to set up and operate the *429RTx[D]*. These functions are not mode specific: they can be used in at least two, or more, different modes.

Functions to handle interrupts in Windows are described at the end of this chapter, **Using Interrupts Under Windows** on page 2-19.

Note: For the *DAS-429[cc]PMC/RTx* board, the software relates to channels 0–9 as module 0; channels 10–19 as module 1.

For the *DAS-429[cc]PMC/RTxD* board, the software relates to channels 0–9 as module 0; channels 10–14 as module 1.

The following functions are described in this chapter:

- Get_DmaAvailable_RT_x
- Get_Error_String_RT_x
- Get_Time_Tag_RT_x
- Get_UseDmalfAvailable_RT_x
- Init_Module_RT_x
- Read_Board_Intr_Status_RT_x
- Read_Board_Status_RT_x
- Read_Chan_Config_Register_RT_x
- Read_Chan_Config_Stat_RT_x
- Read_Global_Start_RT_x
- Read_HwRevision_RT_x
- Read_Number_Of_Channels_RT_x
- Read_Revision_RT_x
- Read_SerialNumber_RT_x
- Release_Module_RT_x
- Reset_Channel_Configuration_RT_x
- Reset_Ttag_RT_x
- Set_IRIG_Timetag_Mode_RT_x
- Set_Prog_Bit_Rate_RT_x
- Set_UseDmalfAvailable_RT_x
- Start_Channel_RT_x
- Start_Selected_Channels_RT_x
- Stop_Channel_RT_x
- Stop_Selected_Channels_RT_x

For Interrupts on PCI[e] and PMC boards, see **Using Interrupts Under Windows** on page 2-19. The following functions are described:

- Get_Interrupt_Count_RT_x
- InitializeInterrupt_RT_x
- Wait_For_Interrupt_RT_x
- Wait_For_Multiple_Interrupts_RT_x

For Interrupts on VME/VXI boards, the interrupt functions are at the carrier board level. See **Using Interrupts Under VISA for VME Carrier Boards** on page 2-23.

Get_DmaAvailable_RTx

Description	Get_DmaAvailable_RTx returns an indicator as to whether Direct Memory Access (DMA) is available for the transfer of data between the host memory and the module memory. See also Set_UseDmalfAvailable_RTx on page 2-15.	
	Note: This function is only for modules on a PCI Express board.	
Syntax	Get_DmaAvailable_RTx (int handle, char *pDmaEnabled)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	pDmaEnabled	A pointer to whether DMA is available. ENABLE_RTX DMA is available [1 H] DISABLE_RTX DMA is not available [0 H]
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Get_Error_String_RTx

Description	Get_Error_String_RTx accepts the error returns from other <i>429RTx & Discrete Software Tools</i> functions. This function returns the string containing a corresponding error message.	
Syntax	Get_Error_String_RTx (int errcode, char* errstring)	
Example:	<pre>char ErrorStr[255]; Get_Error_String_RTx (errorcode, &Errorstr); printf("error is: %s", ErrorStr);</pre>	
Input Parameters	errcode	The error code returned from a Software Tools call.
Output Parameters	errorstring	An array of 255 characters, the message string that contains the corresponding error message. In case of bad input, this function returns a string denoting that.
Return Values	0	Always

Get_Time_Tag_RTx

Description	Get_Time_Tag_RTx returns the running Time Tag of the module in RT and Monitor modes	
Syntax	Get_Time_Tag_RTx (int handle, unsigned int *timetag)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	timetag	32-bit Time Tag.
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Get_UseDmalfAvailable_RTx

Description	Get_UseDmalfAvailable_RTx returns an indicator as to whether DMA will be used for data transfer between the host memory and the module memory, if DMA is available. Note: This function is only for modules on a PCI Express board.	
Syntax	Get_UseDmalfAvailable_RTx (int handle, BOOL *pUseDmaFlag)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	pUseDmaFlag	A pointer to a flag indicating whether DMA will be used for data transfer (if available):
		ENABLE_RTX DMA will be used if available [1 H]
		DISABLE_RTX DMA will not be used [0 H]
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Init_Module_RTx

Description	Init_Module_RTx enables the user to access a module. This is the first function the user must call for each module that is accessed in the application program. All channels are initially disabled, unless specifically enabled. The default setting for all enabled channels is set to receive channel. Transmit channels must be specifically set by the programmer. The function may be called with the SIMULATE [FFFF H] argument. If the SIMULATE argument is used, a portion of the memory equal to the size of the board's dual-port RAM is set aside. This area is then initialized with an id and version number for use in testing programs when no module is available. Multiple modules may be simulated. It is possible to have real and simulated modules in the same application. Before exiting a program, call Release_Module_RTx for each module initialized with Init_Module_RTx.										
Syntax	Init_Module_RTx (usint device_num, usint module_num, usint enabled_channels, usint xmt_channels)										
Input Parameters	<table border="0"> <tr> <td data-bbox="568 882 876 913">device_num</td><td data-bbox="893 882 1438 976">The device number is the index number of the board set in ExcConfig: 0 – 15.</td></tr> <tr> <td colspan="2" data-bbox="568 987 1438 1123"> Note: If only one board is used, the value 25 or the #define value EXC_4000PCI can be used instead of a device number. If more than one board is used the programmer must run the ExcConfig utility to set the device number. </td></tr> <tr> <td data-bbox="568 1123 876 1155"></td><td data-bbox="893 1123 1438 1155">or SIMULATE</td></tr> <tr> <td data-bbox="568 1155 876 1228"></td><td data-bbox="893 1155 1438 1228">Indicating no actual module on a board present [FFFF H]</td></tr> <tr> <td data-bbox="568 1228 876 1260">module_num</td><td data-bbox="893 1228 1438 1507"> The module number of the <i>429RTx & Discrete Software Tools</i> module on the board: 0 – 7 (depending on the board). The value is ignored if device_num is SIMULATE. You can run demo_information_429.exe to check the module number. </td></tr> </table>	device_num	The device number is the index number of the board set in ExcConfig: 0 – 15.	Note: If only one board is used, the value 25 or the #define value EXC_4000PCI can be used instead of a device number. If more than one board is used the programmer must run the ExcConfig utility to set the device number.			or SIMULATE		Indicating no actual module on a board present [FFFF H]	module_num	The module number of the <i>429RTx & Discrete Software Tools</i> module on the board: 0 – 7 (depending on the board). The value is ignored if device_num is SIMULATE. You can run demo_information_429.exe to check the module number.
device_num	The device number is the index number of the board set in ExcConfig: 0 – 15.										
Note: If only one board is used, the value 25 or the #define value EXC_4000PCI can be used instead of a device number. If more than one board is used the programmer must run the ExcConfig utility to set the device number.											
	or SIMULATE										
	Indicating no actual module on a board present [FFFF H]										
module_num	The module number of the <i>429RTx & Discrete Software Tools</i> module on the board: 0 – 7 (depending on the board). The value is ignored if device_num is SIMULATE. You can run demo_information_429.exe to check the module number.										

Init_Module_RTx (cont.)

enabled_channels One or more of the following flags OR'ed together (indicating which channels are enabled):

NO_CHANNELS Only Discrete channels enabled [0 H]

For RT5 modules

CHAN_0 [1 H]
 CHAN_1 [2 H]
 CHAN_2 [4 H]
 CHAN_3 [8 H]
 CHAN_4 [10 H]
 ALL_RT5_CHANNELS [1F H] All channels are enabled

For RT10 modules

CHAN_0 [1 H]
 CHAN_1 [2 H]
 CHAN_2 [4 H]
 CHAN_3 [8 H]
 CHAN_4 [10 H]
 CHAN_5 [20 H]
 CHAN_6 [40 H]
 CHAN_7 [80 H]
 CHAN_8 [100 H]
 CHAN_9 [200 H]
 ALL_RT10_CHANNELS [3FF H]
 All channels are enabled

Note: All channels are initially disabled, unless specifically enabled.

xmt_channels One or more of the following flags OR'ed together (indicating which channels are transmit):

NO_CHANNELS No channels set to transmit – only Discrete channels in use [0 H]

For RT5 modules

CHAN_0 [1 H]
 CHAN_1 [2 H]
 CHAN_2 [4 H]
 CHAN_3 [8 H]
 CHAN_4 [10 H]
 ALL_RT5_CHANNELS [1F H] All channels are set to transmit

For RT10 modules

CHAN_0 [1 H]
 CHAN_1 [2 H]
 CHAN_2 [4 H]
 CHAN_3 [8 H]
 CHAN_4 [10 H]
 CHAN_5 [20 H]
 CHAN_6 [40 H]
 CHAN_7 [80 H]
 CHAN_8 [100 H]
 CHAN_9 [200 H]
 ALL_RT10_CHANNELS [3FF H]
 All channels are set to transmit

Note: All channels are set to receive, unless specifically set to be transmit channels.

Init_Module_RT_x (cont.)**Output Parameters** none

Return values	emodnum	If an invalid module number was specified.
	bad_chan	If an invalid channel was specified.
	eboardtoomany	If too many modules were initialized.
	sim_no_mem	If not enough memory available for simulation.
	enomodule	If no module is present at specified location.
	ewrngmodule	If module specified on the carrier board is not an RT _x module.
	init_failed	If failed to initialize the module/card.
	init_failed_1	If failed to initialize the module/card after first reset.
	init_failed_2	If failed to initialize the module/card after second reset.
	init_failed_3	If failed to initialize the module/card.
	fivechanmod	If tried to enable a channel number greater than 4 on a five channel RT _x module. The module is not initialized.
	sixchancard	If tried to enable a channel number greater than 5 on a six channel card. The card is not initialized.
	sixtransmitchancard	If tried to set more than six channels to transmit on a card that does not support more than six transmit channels. The card is not initialized.
	tenchanmod	If tried to enable a channel number greater than 9 on a ten channel RT _x module. The module is not initialized.
	ekernelcantmap	If a pointer to memory cannot be obtained.
	ekernelnot4000card	If the board is not EXC-4000/8000 family.
	edevtoomany	If Init_Timers_4000 called for too many boards.
	ekernelinitmodule	If error initializing kernel related data.
	ekernelbadparam	If input parameter is invalid.
	eopenkernel	If there was an error opening a device.
	ekernelfrontdeskload	If error loading frontdesk.dll .
	ekernelfrontdesk	If error opening kernel device; check ExcConfig set up.
	eallocresources	If there was an error allocating resources; see Installation Instructions.pdf for details on resource allocation problems.

Init_Module_RT_x (cont.)

ekerneldevicenotopen	If specified device has not been opened.
regnotset	If board is not configured; reboot after ExcConfig is run and board is in slot.
ekernelbadpointer	If output parameter buffer is invalid.
<handle>	If successful, returns the handle to the specified module on the board. This handle is used as the first parameter in all module functions.
	A valid handle is an integer 0 or greater.

Read_Board_Intr_Status_RT_x

Description	Read_Board_Intr_Status_RT _x returns and clears the module/card interrupt status. On an interrupt, this value indicates which channel used the interrupt.	
Syntax	Read_Board_Intr_Status_RT _x (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	<interrupt status>	If successful, returns the module/card interrupt status. Each channel bit is 1, only if the respective channel has an interrupt since the last call to this function.

Bit	Description
10-15	0
00-09	Channel Interrupt Status bits

Read_Board_Status_RT_x

Description	Read_Board_Status_RT _x performs a self-test, then returns the module/card status. The function indicates which channels are installed.	
	Note: You must call Init_Module_RT _x before calling this function. Otherwise, it will fail the self-test.	
Syntax	Read_Board_Status_RT _x (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
Output Parameters	none	

Read_Board_Status_RTx (cont.)

Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<status>	If successful, returns the module/card status.

Bit	Description
14-15	0
13	Extended Time Support 1 = Extended Time is supported 0 = Extended Time is not supported
12	1
11	Host Ready Timeout
10	Module/card memory OK
00-09	Channel Status Bits 1 = channel present (passed self-test) 0 = failed self-test or no channel present

Read_Chan_Config_Register_RTx

Description	Read_Chan_Config_Register_RTx returns the Channel <i>x</i> Configuration register. For values, see the hardware <i>User's Manual</i> for your module or card.	
Syntax	Read_Chan_Config_Register_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Chan_Config_Stat	If an invalid parameter was used as an input.
	<Channel <i>x</i> Configuration register>	If successful, returns the contents of the Channel <i>x</i> Configuration register. For details, see the hardware <i>User's Manual</i> for your module or card.

Read_Chan_Config_Stat_RT_x

Description	Read_Chan_Config_Stat_RT _x returns the Channel <i>x</i> Configuration Status register. For values, see the hardware <i>User's Manual</i> for your module or card.	
Syntax	Read_Chan_Config_Stat_RT _x (int handle, usint channel)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RT _x on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	param_Read_Chan_Config_Stat	If an invalid parameter was used as an input.
	<Channel <i>x</i> Configuration Status register>	If successful, returns the contents of the Channel <i>x</i> Configuration Status register. For details, see the hardware <i>User's Manual</i> for your module or card.

Read_Global_Start_RT_x

Description	Read_Global_Start_RT _x returns the contents of the Global Start register. The function indicates which channels are started.	
Syntax	Read_Global_Start_RT _x (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	<Global Start register>	If successful, returns the contents of the Global Start register.

Bit	Description
10-15	0
00-09	Channel Status Bits 1 = Channel is started 0 = Channel is stopped

Read_HwRevision_RTx

Description	Read_HwRevision_RTx returns the hardware revision number.	
Syntax	Read_HwRevision_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<hardware revision number>	If successful, returns the hardware revision number as a 3-digit hexadecimal number. For example: If a value of 021 (H) is returned, this indicates a hardware revision of 2.1.

Read_Number_Of_Channels_RTx

Description	Read_Number_Of_Channels_RTx returns the number of channels that exist on the module.	
	Note: For more details, such as how many channels can be receive and transmit, see Board Features or Module Features in the Introduction of the user's manual.	
Syntax	Read_Number_Of_Channels_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<number of channels>	If successful, returns the number of channels on the module.

Read_Revision_RTx

Description	Read_Revision_RTx returns the firmware revision number.	
Syntax	Read_Revision_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<firmware revision number>	If successful, returns the firmware revision number. For example: If a value of 0109 (H) is returned, this indicates a firmware revision of 1.09.

Read_SerialNumber_RTx

Description	Read_SerialNumber_RTx returns the module's serial number.	
Syntax	Read_SerialNumber_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<module's serial number>	If successful, returns the module's serial number.

Release_Module_RTx

Description	Release_Module_RTx releases any grabbed resources on a specific module.	
	Call this function for each module initialized with Init_Module_RTx, before exiting a program. To continue accessing the module, call Init_Module_RTx again.	
Syntax	Release_Module_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Reset_Channel_Configuration_RTx

Description	Reset_Channel_Configuration_RTx resets the channel configuration. The Setup_Receive_Channel_RTx function can only be set when all the channels are turned off (via the Stop_Channel_RTx/ Stop_Discrete_RTD functions). The card/module should be started via the Start_Channel_RTx/ Start_Discrete_RTD functions only after a minimum of 1 msec. from the time that the contents of the function have been changed. Note: For boards with Discrete channels, the ARINC 429 channels are set independently from the Discrete channels. Therefore: • Use Start/Stop_Channel_RTx when setting the ARINC channels. • Use Start/Stop_Discrete_RTD when setting the Discrete channels.		
Syntax	Reset_Channel_Configuration_RTx (int handle, uint channel, uint config)		
Input Parameters	handle	The handle designated by Init_Module_RTx.	
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.	
	config	Combination of 1 flag from each of the relevant groups:	
	bit_rate	EXC_BIT_RATE_LO EXC_BIT_RATE_HI BIT_RATE_PROG	12.5 KHz [0 H] 100 KHz [1 H] Bit rate as set in Set_Prog_Bit_Rate_RTx [2 H]
	parity	AR_PARITY_ODD AR_PARITY_EVEN AR_PARITY_OFF	Odd parity [0 H] Even parity [10 H] No parity [8 H]
Transmit channel only			
rise	RISE_HI_SPEED	Tx rise/fall time 1.5 +/- 0.5 µsec. (default) [0 H]	
	RISE_LO_SPEED	Tx rise/fall time 10 +/- 0.5 µsec. [4 H]	

Reset_Channel_Configuration_RTx (cont.)

Receive channel only

wrap _around	NO_WRAP_AROUND	Stop receiving when receiver buffer is full [40 H]
	WRAP_AROUND	Wrap around when receiver buffer is full [0 H]

Output Parameters none

Return Values

ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
bad_chan	If an invalid channel was specified
eboardstarted	If cannot change communication parameters
0	If successful

Reset_Ttag_RTx

Description Reset_Ttag_RTx resets the Time Tag to 0. The function can be called at any time.

Syntax Reset_Ttag_RTx (int handle)

Input Parameters handle The handle designated by Init_Module_RTx.

Output Parameters none

Return Values

ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
0	If successful

Set_IRIG_Timetag_Mode_RTx

Description Set_IRIG_Timetag_Mode_RTx sets the IRIG B mode for all receive channels. The function must be called before a call to Setup_Receive_Channel_RTx. For details on the IRIG B Time Tag format, see **IRIG B Time Tag Format** on page 1-6.

Note: This function is only available for *M4K429RTx* modules Rev. D or later and all *M8K429RT5* modules.

Syntax Set_IRIG_Timetag_Mode_RTx (int handle, uint mode)

Input Parameters handle The handle designated by Init_Module_RTx.

Set_IRIG_Timetag_Mode_RTx (cont.)

	mode	One of the following flags: IRIG_TTAG_MODE Each received Data Word is stored together with a 64-bit IRIG B Time Tag and a Status Word. [10 H] 0 Each received Data Word is stored together with a standard 32-bit Time Tag and a Status Word.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	eNoIrigSupportModule	If the module is not a Nios-based processor and cannot use IRIG-based functions
	param_Set_IRIG_Timetag_Mode	If an invalid mode was selected
	0	If successful

Set_Prog_Bit_Rate_RTx

Description	Set_Prog_Bit_Rate_RTx sets the programmable bit rate for all channels which have programmable bit rate chosen in their Configuration Register.	
Syntax	Set_Prog_Bit_Rate_RTx (int handle , unsigned long hz)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	hz	Minimum value: 2500 Maximum value: 5,000,000
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Prog_Bit_Rate	If an invalid parameter is used as an input.
	0	If successful

Set_UseDmaIfAvailable_RTx

Description	Set_UseDmaIfAvailable_RTx sets whether DMA should be used for data transfer between the host memory and the module memory, if DMA is available. (DMA is enabled by default.) See also Get_DmaAvailable_RTx on page 2-2.		
	Note: This function is only for modules on a PCI Express board.		
Syntax	Set_UseDmaIfAvailable_RTx (int handle, BOOL useDmaFlag)		
Input Parameters	handle	The handle designated by Init_Module_RTx.	
	useDmaFlag	Indicates whether DMA should be used for data transfer (if available):	
		ENABLE_RTX	Use DMA if available [1 H]
		DISABLE_RTX	Do not use DMA [0 H]
Output Parameters	none		
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.	
	0	If successful	

Start_Selected_Channels_RTx

Description	Start_Selected_Channels_RTx simultaneously starts the specified channels. All channels must be set up before they are started.	
	Note: This function avoids the need to wait 500 microseconds between consecutive calls to Start_Channel_RTx (i.e., between successive writes to the Start register).	
Syntax	Start_Selected_Channels_RTx (int handle, usint selected_channels, BOOL keep_existing_as_is)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	selected_channels	One or more of the following flags OR'ed together (indicating which channels are to be started simultaneously):
	For RT5 modules	For RT10 modules
	CHAN_0 [1 H]	CHAN_0 [1 H]
	CHAN_1 [2 H]	CHAN_1 [2 H]
	CHAN_2 [4 H]	CHAN_2 [4 H]
	CHAN_3 [8 H]	CHAN_3 [8 H]
	CHAN_4 [10 H]	CHAN_4 [10 H]
	ALL_RT5_CHANNELS [1F H] All channels are to be started simultaneously	CHAN_5 [20 H]
		CHAN_6 [40 H]
		CHAN_7 [80 H]
		CHAN_8 [100 H]
		CHAN_9 [200 H]
		ALL_RT10_CHANNELS [3FF H] All channels are to be started simultaneously
	Note: To find the number of channels on a module, see Read_Number_Of_Channels_RTx on page 2-10.	
	keep_existing_as_is	TRUE leave all other channels in their current state [1 H] FALSE start the specified channels and stop all other channels [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_chan	If a bad input parameter for selected_channels
	EINVAL	If an invalid parameter is used as an input
	0	If successful

Start_Channel_RT_x

Description	Start_Channel_RT _x starts the specific channel. All channels must be set up before they are started.	
Syntax	Start_Channel_RT _x (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RT _x on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	param_Start_Channel	If an invalid parameter was used as an input
	0	If successful

Stop_Channel_RT_x

Description	Stop_Channel_RT _x stops the specific channel.	
Syntax	Stop_Channel_RT _x (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RT _x on page 2-10. STOPALL To stop all channels [10 Dec]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	param_Start_Channel	If an invalid parameter was used as an input
	0	If successful

Stop_Selected_Channels_RT_x

Description	Stop_Selected_Channels_RT _x simultaneously stops the specified channels.	
Syntax	Stop_Selected_Channels_RT _x (int handle, uint selected_channels)	
Input Parameters	handle	The handle designated by Init_Module_RT _x .
	selected_channels	One or more of the following flags OR'ed together (indicating which channels are to be started simultaneously):
For RT5 modules CHAN_0 [1 H] CHAN_1 [2 H] CHAN_2 [4 H] CHAN_3 [8 H] CHAN_4 [10 H] ALL_RT5_CHANNELS [1F H] All channels are to be stopped simultaneously For RT10 modules CHAN_0 [1 H] CHAN_1 [2 H] CHAN_2 [4 H] CHAN_3 [8 H] CHAN_4 [10 H] CHAN_5 [20 H] CHAN_6 [40 H] CHAN_7 [80 H] CHAN_8 [100 H] CHAN_9 [200 H] ALL_RT10_CHANNELS [3FF H] All channels are to be stopped simultaneously		
Note: To find the number of channels on a module, see Read_Number_Of_Channels_RT _x on page 2-10.		
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RT _x is used.
	bad_chan	If a bad input parameter for selected_channels
	0	If successful

Using Interrupts Under Windows

When writing a Windows program that processes interrupts, a separate thread is generally created to handle the interrupt processing. This thread calls `Wait_For_Interrupt_RT_x`, in order to wait for the next interrupt. When the function returns, the interrupt is processed as needed. This method is demonstrated in the test programs **`demo_int.c`** and **`demo_intms.c`** included with the *429RTx & Discrete Software Tools*.

Note: There is no need to reset the physical interrupt line in the interrupt thread; this is handled internally.

In cases of very high interrupt frequency, several interrupts may occur before the interrupt thread resumes execution. The `Get_Interrupt_Count_RT_x` function may be used to determine if multiple interrupts have occurred. Conversely, it is possible that the `Wait_For_Interrupt_RT_x` function will indicate an interrupt that has already been processed by the thread. (This will occur in the case where a subsequent interrupt occurs in between the return of the `Wait_For_Interrupt_RT_x` function and the call to `Get_Interrupt_Count_RT_x`.) Once again, the `Get_Interrupt_Count_RT_x` function may be used to determine if the interrupt has already been processed.

The following functions are described below:

`Get_Interrupt_Count_RT_x`

`InitializeInterrupt_RT_x`

`Wait_For_Interrupt_RT_x`

`Wait_For_Multiple_Interrupts_RT_x`

Get_Interrupt_Count_RTx

Description	Get_Interrupt_Count_RTx returns the total interrupt count for the specified module from the time the module/card was initialized with Init_[Module/Card]_RTx.	
Syntax	Get_Interrupt_Count_RTx (int handle, unsigned long *pdwInterruptCount)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	pdwInterruptCount	Pointer to an unsigned long which receives the interrupt count
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	egetintcount	If there was a kernel error
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparameter	If input parameter is invalid
	ekernelbadpointer	If output parameter buffer is invalid
	ekerneldevicenotopen	If specified device has not been opened
	0	If successful

InitializeInterrupt_RTx

Description	InitializeInterrupt_RTx may be called to initialize interrupt handling for the given module/card. In general, it is not necessary to call this function since Wait_For_Interrupt_RTx functions initialize the interrupt handling automatically when they are first called. However, in certain situations, such as a program in which the Wait_For_Interrupt_RTx function is not run in a separate thread but is executed sequentially in the main thread, one may wish to initialize the interrupt handling before calling Wait_For_Interrupt_RTx. Thus, if an interrupt occurs after the initialization but before the call to Wait_For_Interrupt_RTx, the latter call will return immediately, reporting the interrupt which occurred previously.	
Syntax	InitializeInterrupt_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Wait_For_Interrupt_RTx

Description	Wait_For_Interrupt_RTx waits for an interrupt on the module/card. It suspends control of the calling thread while waiting, and returns control to the thread upon receipt of the interrupt, or upon expiration of the time out. If <code>timeout</code> is set to INFINITE [FFFFFFFF H], then the call will return only upon receipt of the interrupt.	
Syntax	Wait_For_Interrupt_RTx (int <code>handle</code> , unsigned int <code>timeout</code>)	
Example	Since this function suspends execution of the calling thread, it is generally called from a separate thread, to allow the main thread to continue its processing. An example of a thread routine which waits for interrupts and processes them as they come in is as follows: <pre> DWORD InterruptThread(int referenceParam) { while (1) { int status; status = Wait_For_Interrupt_RTx (module_handle, INFINITE); if (status < 0) { // We don't check for kerneltimeout since we passed // in a timeout value of INFINITE. // All other return values indicate error. // Process error... ExitThread(1); } // Process interrupt... // Check total number of interrupts Get_Interrupt_Count_RTx (module_handle, &numints); } } </pre>	
Input Parameters	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .
	<code>timeout</code>	Timeout is specified in milliseconds, or INFINITE [FFFFFFFF H]
Output Parameters	none	
Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>egeteventhand1</code>	If there is an error in kernel <code>mGetEventHandle</code> , first part
	<code>egeteventhand2</code>	If there is an error in kernel <code>mGetEventHandle</code> , second part
	<code>ekernelinitmodule</code>	If error initializing kernel related data
	<code>ekernelbadparam</code>	If input parameter is invalid
	<code>ekerneldevicenotopen</code>	If specified device was not opened
	Successful if <i>either</i> <code>ekerneltimeout</code>	The wait timed out without receiving an interrupt
	<i>or</i> 0	If successful

Wait_For_Multiple_Interrupts_RT_x

Description	Wait_For_Multiple_Interrupts_RT <i>x</i> waits for an interrupt on any of the specified modules/cards. This function can be used for more than one type of module/card simultaneously. For example an <i>M4K429RTx</i> module and a <i>UNET2</i> . The function suspends control of the calling thread while waiting, and returns control to the thread either upon receipt of the interrupt, or upon expiration of the time out. If <i>timeout</i> is set to INFINITE [FFFFFFFF H], then the call will return only upon receipt of the interrupt.	
Syntax	Wait_For_Multiple_Interrupts_RT <i>x</i> (int numints,int handle_array unsigned int timeout, unsigned long *Interrupt_Bitfield)	
Input Parameters	numints	Number of entries in the handle_array
	handle_array	An array of module handles
	timeout	Timeout is specified in milliseconds, or INFINITE [FFFFFFFF H]
Output Parameters	Interrupt_Bitfield	Pointer to an unsigned long which receives a bit field indicating which of the modules/cards have interrupted (note that more than one module/card may have interrupted simultaneously). The modules/cards are distributed in the bit field such that the lowest bit corresponds to the first module in the handle_list, and so on.
Return Values	egeteventhand1	If there is an error in kernel mGetEventHandleForModule, first part
	egeteventhand2	If there is an error in kernel mGetEventHandleForModule, second part
	ebadhandle	If handle other than the one returned by Init_Module_RT <i>x</i> is used.
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If the specified device was not opened
	ekernelbadpointer	If output parameter buffer is invalid
Successful if <i>either</i>	ekerneltimeout	The wait timed out without receiving an interrupt
<i>or</i>	0	If successful

Using Interrupts Under VISA for VME Carrier Boards

When writing a program under VISA that processes interrupts, the system must be set up to enable signal processing events so the program can receive them into its event handler. The programmer provides this interrupt handler (or 'interrupt service function') as part of the application program. There the user can place any code that is to run in response to receiving an interrupt.

These functions are carrier board-level functions and are described in the *Excalibur Carrier Board Software Tools Programmer's Reference*.

3 ARINC 429 Receive Channels Functions

Chapter 3 describes the functions to set and operate ARINC receive channels on *429RTx[D]* modules and cards.

See **Receive Channel Overview** on page 3-2 and **Receive Channel Setup** on page 3-3 for information on how to set up a receive channel.

Note: For the *DAS-429PMC/RTx* board, the software relates to channels 0–9 as module 0 and channels 10–19 as module 1.
For the *DAS-429[cc]/PMC/RTxD* board, the software relates to channels 0–9 as module 0; channels 10–14 as module 1.

The following functions are described in this chapter:

General Receive Functions

Set_Global_Storage_Mode_RTx
Setup_Receive_Channel_RTx

Translation Functions

Add_Translation_Entry_RTx
Alter_Translation_Entry_RTx
Enable_Translation_Table_RTx
Map_Label_To_Translation_Entry_RTx

Standard Storage Mode and Data Only Storage Mode Functions

Clear_Rcv_Word_Count_RTx	Readback_Filter_Entry_RTx
Clear_Rcvd_Error_Cnt_RTx	Set_Filter_Entry_RTx
Enable_Filter_Table_RTx	Set_Interrupt_Cond_RTx
Read_Channel_Status_RTx	Set_Label_Trigger_RTx
Read_Next_Data_IRIG_RTx	Set_Rcv_Interval_Trig_RTx
Read_Next_Data_RTx	Set_Rcv_Word_Cnt_Trig_RTx
Read_Rcvd_Error_Cnt_RTx	Set_Rcvd_Error_Cnt_RTx
Read_Rcvd_Data_Word_Cnt_RTx	Set_Trigger_Cond_RTx

Merge Storage Mode Functions

Clear_Merge_Word_Count_RTx	Set_Merge_Interval_Trig_RTx
Enable_Merge_Filter_Table_RTx	Set_Merge_Intr_Cond_RTx
Read_Merge_Error_Cnt_RTx	Set_Merge_Label_Trigger_RTx
Read_Merge_Rcvd_Word_Cnt_RTx	Set_Merge_Trig_Cond_RTx
Read_Merge_Status_RTx	Set_Merge_Word_Cnt_Trig_RTx
Read_Next_Merge_Data_IRIG_RTx	Setup_Merge_Mode_RTx
Read_Next_Merge_Data_RTx	

Look-up Table Storage Mode Functions

Enable_Lkup_Table_RTx	Read_Lkup_Current_Lbl_RTx
Enter_Lkup_Entry_RTx	Read_Lkup_Data_RTx

Receive Channel Overview

This section describes each storage mode for receive channels. The next section, **Receive Channel Setup** on page 3-3, provides details on how to set up each mode.

There are three storage modes:

- **Standard Storage Mode** – Standard Storage Mode is the default storage mode. In this mode, data is stored per channel. That is, the data for each channel is stored in a separate area. Each Data Word is stored together with a Time Tag and Status Word.

In Standard Storage Mode, you have the option of storing the data sequentially (default) or you can use the **Look-up Table Storage** submode. When using Look-up Table Storage Mode, an incoming Data Word is stored together with a Time Tag, Error count and Status Word at a location determined by a Look-up Table. You assign separate buffer areas for labels, and only the most recent data associated with each label is saved. Use this mode when only the most recent value of each label is required and the sequence of labels is not important.

- **Merge Storage Mode** – In this mode, data for all channels is stored sequentially in a common area with a Time Tag and Status Word for each Data Word. In Merge Storage Mode, data is stored sequentially; there is no option to use the Look-up Table Storage submode. If data from different channels is to be processed similarly, using Merge Storage Mode is more efficient than reading data from each channel separately.
- **Data Only Storage Mode** – In this mode, data is stored sequentially per channel. That is, the data for each channel is stored in a separate area. Time Tags and the Status Words are not stored. In Data Only Storage Mode, data is stored sequentially; there is no option to use the Look-up Table Storage submode.

Note: Translation functions are not related to any storage mode. When using translation, the module does not record data at all. Its purpose is to immediately retransmit anything it receives after applying the appropriate translation operators.

This section lists the steps for setting up a receive channel in each storage mode.

Memory Usage Limits

The total available buffer space is approximately 64,000 bytes for both receive and transmit. The buffer space can be divided up in any way between the module's channels.

When using a standard (non-IRIG B) Time Tag in Standard Storage Mode or Merge Storage Mode, the module's buffer can store about 6400 ARINC 429 words for all of the module's channels, for both receive and transmit. When using an IRIG B Time Tag, the buffer can store about 4600 ARINC 429 words. In Data Only Storage Mode, the buffer can store about 16,000 ARINC 429 words since the Time Tags and Status Words are not stored.

Transmit messages use the same buffer, but do not usually cause memory space issues unless the bus list is very long.

For more information, see **Appendix A: Data Configuration Returned by Read Data and Load Message Functions**.

Receive Channel Setup

To set up a channel to receive in Standard Storage Mode, call:

1. Set_Global_Storage_Mode_RTx with the STANDARD_MODE argument. This is the default option. page 3-5
2. (Optional) Set_IRIG_Timetag_Mode_RTx, if IRIG B Time Tag format is required. page 2-13
3. Setup_Receive_Channel_RTx to set up a receive channel. page 3-6
4. (Optional) Set_Label_Trigger_RTx to start receiving stored data only upon reception of a specific label. page 3-22
5. (Optional) Set_Rcv_Interval_Trig_RTx and/or Set_Rcv_Word_Cnt_Trig_RTx to generate an interrupt after a certain number of words are received. page 3-22
page 3-23
6. (Optional) Set_Interrupt_Cond_RTx and Set_Trigger_Cond_RTx interrupts or triggers are needed. page 3-21
page 3-24
7. (Optional) Enable_Filter_Table_RTx, if working with a Filter Table, to allow selective storing of labels and interrupts on selected labels. page 3-15
8. (Optional) Enable_Lkup_Table_RTx to set the channel to work in Look-up Table Mode. page 3-34
9. (Optional) Enter_Lkup_Entry_RTx for each label that requires a pointer to be entered to the Look-up Table. page 3-35
10. Start_Channel_RTx, after all the channels are set up, to start each channel. page 2-17
11. To read received data, use: page 3-18
 Read_Next_Data_RTx (when using standard Time Tags), page 3-17
 Read_Next_Data_IRIG_RTx (when using IRIG B Time Tags) or page 3-36
 Read_Lkup_Data_RTx (when using a Look-up Table Mode).

To set up channels to receive in Merge Storage Mode, call:

1. Set_Global_Storage_Mode_RTx with the MERGE_MODE argument. page 3-5
2. (Optional) Set_IRIG_Timetag_Mode_RTx, if IRIG B Time Tag format is required. page 2-13
3. Setup_Receive_Channel_RTx to set up each receive channel. page 3-6

4. Setup_Merge_Mode_RT_x to set the module to work in Merge Storage Mode. page 3-33
5. (Optional) Set_Merge_Interval_Trig_RT_x and/or Set_Merge_Word_Cnt_Trig_RT_x to generate an interrupt after a certain number of words are received. page 3-30
page 3-32
6. (Optional) Set_Merge_Intr_Cond_RT_x and/or Set_Merge_Trig_Cond_RT_x to work with interrupts or triggers. page 3-30
page 3-31
7. (Optional) Enable_Merge_Filter_Table_RT_x , if working with a Filter Table, to allow selective storing of labels and interrupts on selected labels. page 3-15
8. Start_Channel_RT_x after all the channels are set up, to start each channel. page 2-17
9. To read received data, use: page 3-29
Read_Next_Merge_Data_RT_x (when using standard Time Tags) page 3-28
or Read_Next_Merge_Data_IRIG_RT_x (when using IRIG B Time Tags).

To set up a channel to receive in Data Only Storage Mode, call:

1. Set_Global_Storage_Mode_RT_x with the DATA_ONLY_MODE argument. page 3-5
2. Setup_Receive_Channel_RT_x to set up each receive channel. page 3-6
3. (Optional) Set_Label_Trigger_RT_x to start receiving stored data only upon reception of a specific label. page 3-22
4. (Optional) Set_Rcv_Interval_Trig_RT_x and/or Set_Rcv_Word_Cnt_Trig_RT_x to generate an interrupt after a certain number of words are received. page 3-22
5. (Optional) Set_Interrupt_Cond_RT_x and Set_Trigger_Cond_RT_x interrupts or triggers are needed. page 3-21
page 3-24
6. (Optional) Enable_Filter_Table_RT_x, if working with a Filter Table, to allow selective storing of labels and interrupts on selected labels. page 3-15
7. Start_Channel_RT_x, after all the channels are set up, to start each channel. page 2-17
8. To read received data, use Read_Next_Data_RT_x. page 3-18

General Receive Functions

General receive functions can be used in any receive storage mode.

Set_Global_Storage_Mode_RTx

Description	Set_Global_Storage_Mode_RTx sets the storage mode for all receive channels. The function must be called before a call to Setup_Receive_Channel_RTx.	
Syntax	Set_Global_Storage_Mode_RTx (int handle, usint mode)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	mode	STANDARD_MODE Each received Data Word is stored together with a Time Tag and a Status Word, in a separate area for each channel. [0 H]
		DATA_ONLY_MODE Each Data Word is stored <i>without</i> a Time Tag and a Status Word. Look-up Tables cannot be used. [1 H]
		MERGE_MODE Data Words received by the ARINC channels are stored in a common area together with a Time Tag and a Status Word for each Data Word. [2 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Global_Storage_mode	If an invalid parameter is used as an input
	0	If successful

Setup_Receive_Channel_RTx

Description	Setup_Receive_Channel_RTx sets a receive channel to receive. Set_Global_Storage_Mode_RTx <i>must</i> be called before Setup_Receive_Channel_RTx in order to specify the storage mode. If the storage mode is set to Merge Mode, the last parameter is not relevant, but must be supplied. The Setup_Receive_Channel_RTx function can only be set when all the channels are turned off via the Stop_Channel_RTx/ Stop_Discrete_RTD. The card/module should be started via the Start_Channel_RTx/Start_Discrete_RTD functions only after a minimum of 1 msec. from the time that the contents of the function have been changed. Note: For boards with Discrete channels, the ARINC 429 channels are set independently from the Discrete channels. Therefore: • Use Start/Stop_Channel_RTx when setting the ARINC channels. • Use Start/Stop_Discrete_RTD when setting the Discrete channels.		
Syntax	Setup_Receive_Channel_RTx (int handle, uint channel, uint config, uint num_data_words)		
Input Parameters	handle	The handle designated by Init_Module_RTx.	
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.	
	config	Combination of 1 flag from each of the relevant groups:	
	bit_rate	EXC_BIT_RATE_LO EXC_BIT_RATE_HI BIT_RATE_PROG	12.5 KHz [0 H] 100 KHz [1 H] Bit rate as set in Set_Prog_Bit_Rate_RT x on page 2-14 [2 H]
	parity		Odd parity [0 H] Even parity [10 H] No parity [8 H]
	wrap _around	NO_WRAP_AROUND WRAP_AROUND	Stop receiving when receiver buffer is full [40 H] Wrap around when receiver buffer is full [0 H]

Setup_Receive_Channel_RTx (cont.)

num_data
_words

Number of 32-bit ARINC 429 Data Words for which to allocate storage. In:

Standard Mode: Space is automatically allocated for the Time Tags and Status Word.

Merge/Look-up

Table Mode: Set to 0

Note: For information on storage limits, see **Memory Usage Limits** on page 3-2.

Output Parameters

none

ebadhandle

If handle other than the one returned by Init_Module_RTx is used.

Return Values

param_Setup_
Receive_Channel

If an invalid parameter was used as an input.

bad_rcv_chan

If the channel is not an ARINC receive channel

mem_Setup_
Receive_Channel

If the memory allocation failed

eboardstarted
0

If cannot change communication parameters
If successful

Translation Functions

Translation functions are used to receive messages on one channel, modify the messages using one or more translation operators, then retransmit them on the next channel. These functions are not related to any storage mode since the module does not record the data.

Add_Translation_Entry_RTx

Description

Add_Translation_Entry_RTx adds a translation entry that can be applied to any label on any channel. A translation entry defines up to five operations to be performed on an incoming label. To perform an operation, supply a non-zero value as a parameter value. To ignore an operation, supply a 0 as a parameter value. When more than one operation is specified, the operations are performed in the order of this function's parameters.

For example, if non-zero values are supplied for the ANDvalue and ORvalue parameters, the 24 data bits of the incoming label are ANDed with the lowest 24 bits of the ANDvalue, then the result of the AND operation is ORed with the ORvalue. Except for the replace operations, all operations are performed only on the 24 data bits. Assigning a non-zero value to the Skip parameters causes the label not to be transmitted at all.

This function is used in conjunction with Enable_Translation_Table_RTx on page 3-12 and Map_Label_To_Translation_Entry_RTx on page 3-13.

You can modify a previously created translation entry by calling Alter_Translation_Entry_RTx on page 3-10.

Note: This function is only available with firmware revision 2.4 or later.

Syntax

Add_Translation_Entry_RTx (int handle, unsigned int ANDvalue, unsigned int ORvalue, unsigned int XORvalue, unsigned int ADDvalue, unsigned int SUBTRACTvalue, unsigned int NANDvalue, unsigned int NORvalue, unsigned int REPLACEvalue, unsigned int REPLACElabelvalue, unsigned int Skip, unsigned int *TranslationEntryHandle)

Input Parameters

handle	The handle designated by Init_Module_RTx.
ANDvalue	A value to be ANDed with the incoming label's data (1 AND 1 == 1, 1 AND 0 == 0, 0 AND 1 == 0, 0 AND 0 == 0).
ORvalue	A value to be ORed with the incoming label's data (1 OR 1 == 1, 1 OR 0 == 1, 0 OR 1 == 1, 0 OR 0 == 0).

Add_Translation_Entry_RTx (cont.)

	XORvalue	A value to be XORed with the incoming label's data (1 XOR 1 == 0, 1 XOR 0 == 1, 0 XOR 1 == 1, 0 XOR 0 == 0).
	ADDvalue	A value to be added to the incoming label's data; this will not affect the label, but may carry into the SSM bits.
	SUBTRACTvalue	A value to be subtracted from the incoming label's data; this will not affect the label, but may alter the SDI bits.
	NANDvalue	A value to be NANDed with the incoming label's data (1 NAND 1 == 0, 1 NAND 0 == 1, 0 NAND 1 == 1, 0 NAND 0 == 1).
	NORvalue	A value to be NORed with the incoming label data (1 NOR 1 == 0, 1 NOR 0 == 0, 0 NOR 1 == 0, 0 NOR 0 == 1).
	REPLACEvalue	A value to be substituted for the incoming label and data; all 32 bits will be replaced.
	REPLACElabelValue	A value to be substituted for the incoming 8-bit label value; the data will be retransmitted as is.
	Skip	If this value is non-zero, the incoming label will not be retransmitted.
Output Parameters	TranslationEntryHandle	A handle to this translation entry to be used when calling Map_Label_To_Translation_Entry_RTx.
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	mem_Enable_Translation_Entry	If there is insufficient memory for a new translation table entry or there are more than five translation operations defined in the translation entry
	0	If successful

Alter_Translation_Entry_RTx

Description	Alter_Translation_Entry_RTx modifies a previously added translation entry that was added by calling Add_Translation_Entry_RTx. A translation entry that can be applied to any label on any channel. A translation entry defines up to five operations to be performed on an incoming label. To perform an operation, supply a non-zero value as a parameter value. To ignore an operation, supply a 0 as a parameter value. When more than one operation is specified, the operations are performed in the order of this function's parameters. For example, if non-zero values are supplied for the ANDvalue and ORvalue parameters, the 24 data bits of the incoming label are ANDed with the lowest 24 bits of the ANDvalue, then the result of the AND operation is ORed with the ORvalue. Except for the replace operations, all operations are performed only on the 24 data bits. Assigning a non-zero value to the Skip parameters causes the label not to be transmitted at all. This function is used in conjunction with Enable_Translation_Table_RTx on page 3-12 and Map_Label_To_Translation_Entry_RTx on page 3-13. Note: This function is only available with firmware revision 2.4 or later.										
Syntax	Add_Translation_Entry_RTx (int handle, unsigned int ANDvalue, unsigned int ORvalue, unsigned int XORvalue, unsigned int ADDvalue, unsigned int SUBTRACTvalue, unsigned int NANDvalue, unsigned int NORvalue, unsigned int REPLACEvalue, unsigned int REPLACElabelvalue, unsigned int Skip, unsigned int *TranslationEntryHandle)										
Input Parameters	<table> <tr> <td data-bbox="597 1318 738 1346">handle</td><td data-bbox="841 1318 1453 1346">The handle designated by Init_Module_RTx.</td></tr> <tr> <td data-bbox="597 1360 738 1388">ANDvalue</td><td data-bbox="841 1360 1453 1461">A value to be ANDed with the incoming label's data (1 AND 1 == 1, 1 AND 0 == 0, 0 AND 1 == 0, 0 AND 0 == 0).</td></tr> <tr> <td data-bbox="597 1476 722 1503">ORvalue</td><td data-bbox="841 1476 1453 1577">A value to be ORed with the incoming label's data (1 OR 1 == 1, 1 OR 0 == 1, 0 OR 1 == 1, 0 OR 0 == 0).</td></tr> <tr> <td data-bbox="597 1591 738 1619">XORvalue</td><td data-bbox="841 1591 1453 1692">A value to be XORed with the incoming label's data (1 XOR 1 == 0, 1 XOR 0 == 1, 0 XOR 1 == 1, 0 XOR 0 == 0).</td></tr> <tr> <td data-bbox="597 1707 738 1734">ADDvalue</td><td data-bbox="841 1707 1453 1801">A value to be added to the incoming label's data; this will not affect the label, but may carry into the SSM bits.</td></tr> </table>	handle	The handle designated by Init_Module_RTx.	ANDvalue	A value to be ANDed with the incoming label's data (1 AND 1 == 1, 1 AND 0 == 0, 0 AND 1 == 0, 0 AND 0 == 0).	ORvalue	A value to be ORed with the incoming label's data (1 OR 1 == 1, 1 OR 0 == 1, 0 OR 1 == 1, 0 OR 0 == 0).	XORvalue	A value to be XORed with the incoming label's data (1 XOR 1 == 0, 1 XOR 0 == 1, 0 XOR 1 == 1, 0 XOR 0 == 0).	ADDvalue	A value to be added to the incoming label's data; this will not affect the label, but may carry into the SSM bits.
handle	The handle designated by Init_Module_RTx.										
ANDvalue	A value to be ANDed with the incoming label's data (1 AND 1 == 1, 1 AND 0 == 0, 0 AND 1 == 0, 0 AND 0 == 0).										
ORvalue	A value to be ORed with the incoming label's data (1 OR 1 == 1, 1 OR 0 == 1, 0 OR 1 == 1, 0 OR 0 == 0).										
XORvalue	A value to be XORed with the incoming label's data (1 XOR 1 == 0, 1 XOR 0 == 1, 0 XOR 1 == 1, 0 XOR 0 == 0).										
ADDvalue	A value to be added to the incoming label's data; this will not affect the label, but may carry into the SSM bits.										

Alter_Translation_Entry_RTx (cont.)

SUBTRACTvalue	A value to be subtracted from the incoming label's data; this will not affect the label, but may alter the SDI bits.
NANDvalue	A value to be Nanded with the incoming label's data (1 NAND 1 == 0, 1 NAND 0 == 1, 0 NAND 1 == 1, 0 NAND 0 == 1).
NORvalue	A value to be NORed with the incoming label data (1 NOR 1 == 0, 1 NOR 0 == 0, 0 NOR 1 == 0, 0 NOR 0 == 1).
REPLACEvalue	A value to be substituted for the incoming label and data; all 32 bits will be replaced.
REPLACElabelvalue	A value to be substituted for the incoming 8-bit label value; the data will be retransmitted as is.
Skip	If this value is non-zero, the incoming label will not be retransmitted.
TranslationEntryHandle	The handle of the translation table entry. This was the output parameter of Add_Translation_Entry_RTx when the translation table entry was created.
Output Parameters	none
Return Values	ebadhandle If handle other than the one returned by Init_Module_RTx is used. mem_Enable_Translation_Entry If there is insufficient memory for an new translation table entry or there are more than five translation operations defined in the translation entry 0 If successful

Enable_Translation_Table_RTx

Description	Enable_Translation_Table_RTx allocates space for a translation table, defines a channel as a translation receive channel and allocates the next channel (channel + 1) as the associated transmit channel over which all translated labels will be retransmitted. It must be called before any calls to Map_Label_To_Translation_Entry_RTx. This function is used in conjunction with Add_Translation_Entry_RTx on page 3-8 and Map_Label_To_Translation_Entry_RTx on page 3-13. Note: This function is only available with firmware revision 2.4 or later.	
Syntax	Enable_Translation_Table_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel to receive the labels, 0 – 8 or 0 – 4, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10. The next channel will be used to transmit the translated labels. Therefore, the receive channel cannot be the highest channel on the module.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_rcv_chan	If the channel is not an ARINC receive channel
	bad_tx_chan	If not an ARINC transmit channel
	mem_Enable_Translation_Table	If there is not enough memory available for a translation table
	0	If successful

Map_Label_To_Translation_Entry_RTx

Description	Map_Label_To_Translation_Entry_RTx associates a channel/label combination with a translation table entry previously defined by calling Add_Translation_Entry_RTx. Map_Label_To_Translation_Entry_RTx causes all incoming labels whose 8-bit label value matches the <code>label</code> parameter defined in this function, to be translated according to the operations defined in the translation table entry. The resulting message is then transmitted on the next channel (<code>channel + 1</code>). This function can only be called for channels for which Enable_Translation_Table_RTx has been called. See Add_Translation_Entry_RTx on page 3-8 and Enable_Translation_Table_RTx on page 3-12. Note: This function is only available with firmware revision 2.4 or later.	
Syntax	Map_Label_To_Translation_Entry_RTx (int <code>handle</code> , uint <code>channel</code> , unsigned int <code>label</code> , unsigned int <code>TranslationEntryHandle</code>)	
Input Parameters	<code>handle</code>	The handle designated by Init_Module_RTx.
	<code>channel</code>	The channel to which to apply the translation table entry.
	<code>label</code>	The 8-bit label to which to apply the translation table entry.
	<code>TranslationEntryHandle</code>	The handle of the translation table entry. This was the output parameter of Add_Translation_Entry_RTx when the translation table entry was created.
Output Parameters	<code>none</code>	
Return Values	<code>ebadhandle</code>	If <code>handle</code> other than the one returned by Init_Module_RTx is used.
	<code>bad_rcv_chan</code>	If the channel is not an ARINC receive channel
	<code>param_Enable_Translation_Table</code>	If Enable_Translation_Table_RTx was not called for this channel
	<code>no_translation_table</code>	If an attempt was made to map to a translation entry on a channel with no translation table
	<code>0</code>	If successful

Standard Storage Mode and Data Only Storage Mode Functions

Clear_Rcv_Word_Count_RTx

Description	Clear_Rcv_Word_Count_RTx resets the received word count to 0. It should be called only when the channel is inactive, that is, the start is bit set to 0.	
Syntax	Clear_Rcv_Word_Count_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Rcv_Word_Count	If an invalid parameter was used as an input.
	0	If successful

Clear_Rcvd_Error_Cnt_RTx

Description	Clear_Rcvd_Error_Cnt_RTx clears the register containing the number of errors encountered on a channel.	
Syntax	Clear_Rcvd_Error_Cnt_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Rcvd_Error_Cnt	If channel number is out of the valid range
	0	If successful

Enable_Filter_Table_RTx

Description	Enable_Filter_Table_RTx sets up a channel to receive only those Data Words that contain a label that has been enabled in the Filter Table. An interrupt is issued when a label is received that has the interrupt bit entered in the Filter Table.									
Syntax	Enable_Filter_Table_RTx (int handle, usint channel, usint *table_ptr)									
Example	To set up Filter Table if you want to store only label a5 usint MyFilterTable[256]={0}; MyFilterTable[0xa5] = 0x01; Enable_Filter_Table(rcvchan, MyFilterTable);									
Input Parameters	handle	The handle designated by Init_Module_RTx.								
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.								
	table_ptr	The address of a 256-word array. Word 0 of the array contains the Control word for label 0, word 1 for label 1 etc.								
<table><tr><th>Bit</th><th>Description</th></tr><tr><td>02-07</td><td>0</td></tr><tr><td>01</td><td>0 = Do not interrupt 1 = Interrupt</td></tr><tr><td>00</td><td>0 = Do not store 1 = Store Word</td></tr></table>			Bit	Description	02-07	0	01	0 = Do not interrupt 1 = Interrupt	00	0 = Do not store 1 = Store Word
Bit	Description									
02-07	0									
01	0 = Do not interrupt 1 = Interrupt									
00	0 = Do not store 1 = Store Word									
NO_FILTER_TABLE_RTX Cancels a Filter Table operation [FFFFFFFF H]										
Output Parameters	none									
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.								
	param_Enable_Filter_Table	If an invalid parameter was used as an input.								
	mem_Enable_Filter_Table	If the memory allocation failed.								
	0	If successful								

Read_Channel_Status_RTx

Description	Read_Channel_Status_RTx returns and clears the Interrupt status of the specified channel.	
Input Parameters	Read_Channel_Status_RTx (int handle, int channel)	
Syntax	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Channel_Status	If an invalid parameter was used as an input.
	One or more of the following flags:	
	LABEL_RECEIVED set upon reception of a label which was enabled for interrupt in a Look-up Table or Filter Table [4 H]	
	INTERVAL_CNT_TRIG set when a received interval count trigger occurs [8 H] (see Set_Rcv_Interval_Trig_RTx on page 3-22)	
	WORD_CNT_TRIG set when a received word count trigger occurs [10 H] (see Set_Rcv_Word_Cnt_Trig_RTx on page 3-23).	
	ERROR_RECEIVED set when a receive error is detected [20 H]	
	STOP_ON_BUFFER_FULL Set when reception is stopped due to full receive buffer [40 H]	
	0	If successful

Read_Next_Data_IRIG_RTx

Description	Read_Next_Data_IRIG_RTx copies received data from the module's/ card's receive buffer to the array specified by 'msgptr'. The first call to this function copies data beginning with the oldest word in the receive buffer. On subsequent calls Read_Next_Data_IRIG_RTx resumes copying data where the previous call left off. If the entire buffer has been filled since the last time Read_Next_Data_IRIG_RTx was called, some unread data may be overwritten by the new data. This will be reported in the output parameter. Note: • This function should be used when using IRIG B Time Tags. Otherwise use Read_Next_Data_RTx. See Read_Next_Data_RTx on page 3-18. • This function is only available for <i>M4K429RTx</i> modules Rev. D or later (and all <i>M8K429RT5</i> modules) on a carrier board that has IRIG B wired to the module.	
Syntax	Read_Next_Data_IRIG_RTx (int handle, usint channel, usint num_data_words, usint *msgptr, int *overwritten)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	num_data_words	Number of 32-bit ARINC 429 Data Words to read.
Output Parameters	msgptr	Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions .
	overwritten	DATA_OVERWRITTEN Old data overwritten by new data [-1] NOT_OVERWRITTEN No data was overwritten [0]
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Next_Data	If an invalid parameter was used as an input.
	param_Read_Next_Data_IRIG	If this function was used in DATA_ONLY_MODE; DATA_ONLY_MODE is not legal in IRIG_TTAG_MODE.
	eNoIrigSupportModule	If the module is not a Nios-based processor and cannot use IRIG-based functions

Read_Next_Data_IRIG_RTx (cont.)

ewrongmode	If not in IRIG_TTAG_MODE
<number of words read>	If successful, returns the number of words read

Read_Next_Data_RTx**Description**

Read_Next_Data_RTx copies received data from the module's/ card's receive buffer to the array specified by 'msgptr'. The first call to this function copies data beginning with the oldest word in the receive buffer. On subsequent calls Read_Next_Data_RTx resumes copying data where the previous call left off.

If the entire buffer has been filled since the last time Read_Next_Data_RTx was called, some unread data may be overwritten by the new data. This will be reported in the output parameter.

Note: When using IRIG B Time Tags, use Read_Next_Data_IRIG_RTx instead. See Read_Next_Data_IRIG_RTx on page 3-17.

Syntax

Read_Next_Data_RTx (int handle, uint channel, uint num_data_words, uint *msgptr, int *overwritten)

Input Parameters

handle	The handle designated by Init_Module_RTx.
channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
num_data_words	Number of 32-bit ARINC 429 Data Words to read

Output Parameters

msgptr	Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions.
overwritten	DATA_OVERWRITTEN Old data overwritten by new data [-1] NOT_OVERWRITTEN No data was overwritten [0]

Return Values

ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
param_Read_Next_Data	If an invalid parameter was used as an input.
<number of words read>	If successful, returns the number of words read

Read_Rcvd_Error_Cnt_RTx

Description	Read_Rcvd_Error_Cnt_RTx returns the number of receive errors detected by the specified channel, since the last call to Setup_Receive_Channel_RTx.	
	Note: This is a 16-bit counter, which returns to 0 after reaching 65,535.	
Syntax	Read_Rcvd_Error_Cnt_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Rcvd_Error_Cnt	If an invalid parameter was used as an input
	<number of receive errors>	If successful, returns the number of receive errors

Read_Rcvd_Data_Word_Cnt_RTx

Description	Read_Rcvd_Data_Word_Cnt_RTx returns the number of received 32-bit ARINC 429 Data Words since the last call to Setup_Receive_Channel_RTx.	
	Note: This is a 16-bit counter, which returns to 0 after reaching 65,535.	
Syntax	Read_Rcvd_Data_Word_Cnt_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Rcvd_Data_Word_Cnt	If an invalid parameter was used as an input
	<number of words read>	If successful, returns the number of words read

Readback_Filter_Entry_RTx

Description	Readback_Filter_Entry_RTx reads back one Filter Table entry of a receive channel. The function enables the programmer to read back data written to the dual-port RAM.	
Syntax	Readback_Filter_Entry_RTx (int handle, uint channel, uchar label)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	label	The label of the filter entry
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_chan	If an invalid channel is specified
	bad_rcv_chan	If the channel is not an ARINC receive channel
	no_filter_table	If no Filter Table is defined
	<Filter Table entry>	If successful, returns a Filter Table entry

Set_Filter_Entry_RTx

Description	Set_Filter_Entry_RTx sets one Filter Table entry of a receive channel.	
Syntax	Set_Filter_Entry_RTx(int handle, uint channel, uchar label, uint newentry)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	label	The label of the filter entry
	newentry	The Filter Table entry
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_chan	If an invalid channel is specified
	bad_rcv_chan	If the channel is not an ARINC receive channel
	no_filter_table	If no Filter Table is defined
	0	If successful

Set_Interrupt_Cond_RTx

Description	Set_Interrupt_Cond_RTx sets the condition or conditions under which the specified channel will issue an interrupt. The default is for no interrupts to be generated. Interrupts can be cancelled by stopping the channel and calling Set_Interrupt_Cond_RTx with the argument 'condition' set to NO_INTERRUPTS.	
Syntax	Set_Interrupt_Cond_RTx (int handle, usint channel, usint condition)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	condition	One or more of the following values: LABEL_RECEIVED Received a label enabled for interrupts in the Filter Table or Look-up Table [4 H] INTERVAL_CNT_TRIG The received word count is a multiple of the interval specified in Set_Rcv_Interval_Trig_RTx on page 3-22 [8 H] WORD_CNT_TRIG Received word count matches count specified in Set_Rcv_Word_Cnt_Trig_RTx on page 3-23 [10 H] ERROR_RECEIVED A word with an error injection was received [20 H] STOPPED_ON_BUFFER_FULL The channel is set to stop reception when the buffer is full. Only valid if NO_WRAP_AROUND Mode is selected when the receive channel is set up [40 H] NO_INTERRUPTS Cancels interrupts [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Interrupt_Cond	If an invalid parameter is used as an input
	noirqset	If no interrupt is allocated
	0	If successful

Set_Label_Trigger_RTx

Description	Set_Label_Trigger_RTx sets up the channel to start storing received data only after a specified label is received. From this point onwards, all data received with this label is stored.	
Syntax	Set_Label_Trigger_RTx (int handle, uint channel, unsigned char label)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	label	The label which triggers data to be stored.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Label_Trigger	If the parameter is out of range
	0	If successful

Set_Rcv_Interval_Trig_RTx

Description	Set_Rcv_Interval_Trig_RTx sets the value for the interval count trigger. This sets up the channel to set a bit in the Channel Status Register and to issue an interrupt and/or a trigger every time the received word count is a multiple of the specified interval. This function must be called prior to calls to: Set_Interrupt_Cond_RTx on page 3-21 <i>or</i> Set_Trigger_Cond_RTx on page 3-24	
Syntax	Set_Rcv_Interval_Trig_RTx (int handle, uint channel, uint interval)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	interval	The size of the desired interval: A value 0 – 65535 NO_TRIGGER Cancels the trigger [0 H]
Output Parameters	none	

Set_Rcv_Interval_Trig_RTx (cont.)

Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>param_Set_Rcv_Interval_Trig</code>	If an invalid parameter is used as an input
	<code>0</code>	If successful

Set_Rcv_Word_Cnt_Trig_RTx

Description	Set_Rcv_Word_Cnt_Trig_RTx sets the value for the word count trigger. It must be called prior to calls to: Set_Interrupt_Cond_RTx on page 3-21 <i>or</i> Set_Trigger_Cond_RTx on page 3-24	
Syntax	Set_Rcv_Word_Cnt_Trig_RTx (int handle, usint channel, usint count)	
Input Parameters	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .
	<code>channel</code>	The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.
	<code>count</code>	The word count which causes the trigger
Output Parameters	<code>none</code>	
Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>param_Set_Rcv_Word_Cnt_Trig</code>	If an invalid parameter is used as an input
	<code>0</code>	If successful

Set_Rcvd_Error_Cnt_RTx

Description	Set_Rcvd_Error_Cnt_RTx sets the register containing the number of errors encountered on a channel to a specified value.	
Syntax	Set_Rcvd_Error_Cnt_RTx (int handle, usint channel, usint value)	
Input Parameters	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .
	<code>channel</code>	The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.
	<code>value</code>	The value to store in the register.
Output Parameters	<code>none</code>	
Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>0</code>	If successful

Set_Rcvd_Error_Cnt_RTx (cont.)

param_Read_Rcvd_Error_Cnt	If channel number is out of the valid range
0	If successful

Set_Trigger_Cond_RTx

Description	Set_Trigger_Cond_RTx sets the condition or conditions under which the specified channel issues a trigger. The default is for no triggers to be issued.	
Syntax	Set_Trigger_Cond_RTx (int handle, uint channel, uint condition)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	condition	One or more of the following values: LABEL_RECEIVED Received a label enabled for interrupt in the Filter Table or Look-up Table [4 H] INTERVAL_CNT_TRIG The received word count is a multiple of the interval specified in Set_Rcv_Interval_Trig_RTx on page 3-22 [8 H] WORD_CNT_TRIG Received word count matches count specified in Set_Rcv_Word_Cnt_Trig_RTx on page 3-23 [10 H] ERROR_RECEIVED A word with an error condition was received [20 H] STOP_ON_BUFFER_FULL The channel is set to stop reception when the buffer is full. Only valid if NO_WRAP_AROUND Mode is selected when the receive channel is set up [40 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Trigger_Cond	If an invalid parameter is used as an input
	0	If successful

Merge Storage Mode Functions

Clear_Merge_Word_Count_RTx

Description	Clear_Merge_Word_Count_RTx sets the received word count to zero. The function should only be called if all the ARINC channels are inactive, otherwise, the received word count will be meaningless.	
Syntax	Clear_Merge_Word_Count_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Enable_Merge_Filter_Table_RTx

Description	Enable_Merge_Filter_Table_RTx sets Merge Mode to receive only those Data Words that contain a label that has been enabled in the Filter Table. An interrupt is issued upon reception of a label whose entry in the Filter Table so indicates.	
Syntax	Enable_Merge_Filter_Table_RTx (int handle, usint *table_ptr)	
Example	To set up a Filter Table, to store only label A5 [H]: <pre>usint MyFilterTable[256]={0}; MyFilterTable[0xa5] = 0x01; Enable_Filter_Table(rcvchan, MyFilterTable);</pre>	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	table_ptr	The address of a 256-byte array. Byte 0 of the array contains the Control byte for label 0, byte 1 for label 1 etc.

Bit	Description
02-15	0
01	0 = Do not interrupt 1 = Interrupt
00	0 = Do not store 1 = Store Word

NO_FILTER_TABLE_RTX

Cancels a Filter Table operation. Stop all cards/modules before cancelling a Filter Table operation, otherwise the command will take effect only the next time the card/module is started [FFFFFFFF H]

Enable_Merge_Filter_Table_RTx (cont.)

Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	mem_Enable_Merge_Filter_Table	If the memory allocation failed
	0	If successful

Read_Merge_Error_Cnt_RTx

Description	Read_Merge_Error_Cnt_RTx returns the received error count in Merge Mode. Note: This is a 16-bit counter, which returns to 0 after reaching 65,535.	
Syntax	Read_Merge_Error_Cnt_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<global error count>	If successful, returns the global error count

Read_Merge_Rcvd_Word_Cnt_RTx

Description	Read_Merge_Rcvd_Word_Cnt_RTx returns the received word count in Merge Mode. Note: This is a 16-bit counter, which returns to 0 after reaching 65,535.	
Syntax	Read_Merge_Rcvd_Word_Cnt_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<number of received Data Words>	If successful, returns the number of received 32-bit ARINC 429 Data Words stored in Merge Mode since the last call to Setup_Merge_Mode_RTx.

Read_Merge_Status_RTx

Description	Read_Merge_Status_RTx returns and clears the Merge Interrupt Status.	
Syntax	Read_Merge_Status_RTx (int handle)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	<interrupt status>	If successful, returns the interrupt status as a combination of the following flags: LABEL_RECEIVED set upon reception of a label which was enabled for interrupt in a Look-up Table or Filter Table [4 H] INTERVAL_CNT_TRIG set when a received interval count trigger occurs [8 H] (see Set_Merge_Interval_Trig_RTx on page 3-30) WORD_CNT_TRIG set when a received word count trigger occurs [10 H] (see Set_Merge_Word_Cnt_Trig_RTx on page 3-32) ERROR_RECEIVED set when a receive error is detected [20 H] STOP_ON_BUFFER_FULL set when reception is stopped due to a full receive buffer [40 H]

Read_Next_Merge_Data_IRIG_RTx

Description	Read_Next_Merge_Data_IRIG_RTx copies received 32-bit ARINC 429 Data Words together with their associated Time Tags and Status Words from the module's/card's common storage area to the array pointed to by <code>msgptr</code>. The first call to this function copies data starting with the oldest word in the common storage area. On the next and subsequent calls, Read_Next_Merge_Data_IRIG_RTx resumes copying data where the previous calls left off. Note: • This function should be used when using IRIG B Time Tags. Otherwise use Read_Next_Merge_Data_RTx. See Read_Next_Merge_Data_RTx on page 3-29. • This function is only available for <i>M4K429RTx</i> modules Rev. D or later (and all <i>M8K429RT5</i> modules) on a carrier board that has IRIG B wired to the module.	
Syntax	Read_Next_Merge_Data_IRIG_RTx (int handle, usint num_data_words, usint *msgptr, int *overwritten)	
Input Parameters	<code>handle</code> The handle designated by Init_Module_RTx. <code>num_data_words</code> Number of 32-bit ARINC 429 Data Words to read. The maximum number of Data Words to be copied is specified by <code>num_data_words</code>. The size of the specified array, where each element is a 16-bit word, must be at least 7× <code>num_data_words</code> 16-bit words in order to accommodate Data, Time Tag and Status Word.	
Output Parameters	<code>msgptr</code> Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions. <code>overwritten</code> DATA_OVERWRITTEN Old data was overwritten by new data [-1] NOT_OVERWRITTEN Data stored successfully; no data was overwritten [0]	
Return Values	<code>ebadhandle</code> If handle other than the one returned by Init_Module_RTx is used. <code>eNoIrigSupportModule</code> If the module is not a Nios-based processor and cannot use IRIG-based functions <code>ewrongmode</code> If not in IRIG_TTAG_MODE <code><number of words read></code> If successful, returns the number of words read	

Read_Next_Merge_Data_RTx

Description	Read_Next_Merge_Data_RTx copies received 32-bit ARINC 429 Data Words together with their associated Time Tags and Status Words from the module's/card's common storage area to the array pointed to by <code>msgptr</code>. The first call to this function copies data starting with the oldest word in the common storage area. On the next and subsequent calls, <code>Read_Next_Merge_Data_RTx</code> resumes copying data where the previous calls left off. Note: When using IRIG B Time Tags, use <code>Read_Next_Merge_Data_IRIG_RTx</code> instead. See <code>Read_Next_Merge_Data_IRIG_RTx</code> on page 3-28.				
Syntax	<code>Read_Next_Merge_Data_RTx (int handle, uint num_data_words, uint *msgptr, int *overwritten)</code>				
Input Parameters	<table> <tr> <td data-bbox="597 766 706 793"><code>handle</code></td><td data-bbox="803 766 1443 793">The handle designated by <code>Init_Module_RTx</code>.</td></tr> <tr> <td data-bbox="597 808 755 871"><code>num_data_words</code></td><td data-bbox="803 808 1443 1134"> Number of 32-bit ARINC 429 Data Words to read. The maximum number of Data Words to be copied is specified by <code>num_data_words</code>. The size of the specified array, where each element is a 16-bit word, must be at least 5× <code>num_data_words</code> 16-bit words in order to accommodate Data, Time Tag and Status Word. </td></tr> </table>	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .	<code>num_data_words</code>	Number of 32-bit ARINC 429 Data Words to read. The maximum number of Data Words to be copied is specified by <code>num_data_words</code>. The size of the specified array, where each element is a 16-bit word, must be at least 5× <code>num_data_words</code> 16-bit words in order to accommodate Data, Time Tag and Status Word.
<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .				
<code>num_data_words</code>	Number of 32-bit ARINC 429 Data Words to read. The maximum number of Data Words to be copied is specified by <code>num_data_words</code>. The size of the specified array, where each element is a 16-bit word, must be at least 5× <code>num_data_words</code> 16-bit words in order to accommodate Data, Time Tag and Status Word.				
Output Parameters	<table> <tr> <td data-bbox="597 1144 706 1171"><code>msgptr</code></td><td data-bbox="803 1144 1443 1249"> Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions. </td></tr> <tr> <td data-bbox="597 1260 771 1323"><code>overwritten</code></td><td data-bbox="803 1260 1443 1449"> <code>DATA_OVERWRITTEN</code> Old data was overwritten by new data [-1] <code>NOT_OVERWRITTEN</code> Data stored successfully; no data was overwritten [0] </td></tr> </table>	<code>msgptr</code>	Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions.	<code>overwritten</code>	<code>DATA_OVERWRITTEN</code> Old data was overwritten by new data [-1] <code>NOT_OVERWRITTEN</code> Data stored successfully; no data was overwritten [0]
<code>msgptr</code>	Data returned See Appendix A: Data Configuration Returned by Read Data and Load Message Functions.				
<code>overwritten</code>	<code>DATA_OVERWRITTEN</code> Old data was overwritten by new data [-1] <code>NOT_OVERWRITTEN</code> Data stored successfully; no data was overwritten [0]				
Return Values	<table> <tr> <td data-bbox="597 1459 755 1486"><code>ebadhandle</code></td><td data-bbox="803 1459 1443 1522">If handle other than the one returned by <code>Init_Module_RTx</code> is used.</td></tr> <tr> <td data-bbox="597 1533 755 1600"><number of words read></td><td data-bbox="803 1533 1443 1560">If successful, returns the number of words read</td></tr> </table>	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.	<number of words read>	If successful, returns the number of words read
<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.				
<number of words read>	If successful, returns the number of words read				

Set_Merge_Interval_Trig_RTx

Description	Set_Merge_Interval_Trig_RTx sets the value of the interval count trigger. It must be set prior to calls to: Set_Merge_Intr_Cond_RTx on page 3-30 <i>or</i> Set_Merge_Trig_Cond_RTx on page 3-31	
Syntax	Set_Merge_Interval_Trig_RTx (int handle, usint interval)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	interval	The requested interval A value 0 – 65535
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Set_Merge_Intr_Cond_RTx

Description	Set_Merge_Intr_Cond_RTx sets the condition or conditions for Merge Mode to issue an interrupt. The default is for no interrupts to be issued.	
Syntax	Set_Merge_Intr_Cond_RTx (int handle, usint condition)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	condition	LABEL_RECEIVED Set upon reception of a label which was enabled for interrupt in a Look-up Table or Filter Table [4 H] INTERVAL_CNT_TRIG The received word count is a multiple of interval specified in Set_Merge_Interval_Trig_RTx on page 3-30 [8 H] WORD_CNT_TRIG Issue an interrupt every time the received Word count matches count specified in Set_Merge_Word_Cnt_Trig_RTx on page 3-32 [10 H] ERROR_RECEIVED A word with an error condition was received [20 H] STOP_ON_BUFFER_FULL The channel is set to stop reception when the buffer is full. Only valid if NO_WRAP_AROUND Mode is selected when the receive channel is set up [40 H]

Set_Merge_Intr_Cond_RTx (cont.)

NO_INTERRUPTS

Cancels interrupts [0 H]

Output Parameters none

Return Values ebadhandle If handle other than the one returned by Init_Module_RTx is used.

noirqset No interrupt allocated

0 If successful

Set_Merge_Label_Trigger_RTx

Description Set_Merge_Label_Trigger_RTx sets up Merge Mode to start storing received data only on receiving a specified label the first time.

Syntax Set_Merge_Label_Trigger_RTx (int handle, unsigned char label)

Input Parameters handle The handle designated by Init_Module_RTx.

label The first label to be stored

Output Parameters none

Return Values ebadhandle If handle other than the one returned by Init_Module_RTx is used.

0 If successful

Set_Merge_Trig_Cond_RTx

Description Set_Merge_Trig_Cond_RTx sets the condition or conditions under which Merge Mode issues a trigger. The default is for no triggers to be issued.

Syntax Set_Merge_Trig_Cond_RTx (int handle, uint condition)

Input Parameters handle The handle designated by Init_Module_RTx.

condition LABEL_RECEIVED
Set upon reception of a label which was enabled for interrupt in a Look-up Table or Filter Table [4 H]

INTERVAL_CNT_TRIG
Set when the received word count is a multiple of interval specified in **Set_Merge_Interval_Trig_RTx** on page 3-30 [8 H]

WORD_CNT_TRIG
Issue an interrupt every time the received Word count matches count specified in **Set_Merge_Word_Cnt_Trig_RTx** on page 3-32 [10 H]

Set_Merge_Trig_Cond_RTx (cont.)**ERROR_RECEIVED**

A word with an error condition was received [20 H]

STOP_ON_BUFFER_FULL

The channel is set to stop reception when the buffer is full. Only valid if

NO_WRAP_AROUND Mode is selected when the receive channel is set up [40 H]

NO_INTERRUPTS

Cancels interrupts [0 H]

Output Parameters none

Return Values ebadhandle If handle other than the one returned by Init_Module_RTx is used.
0 If successful

Set_Merge_Word_Cnt_Trig_RTx

Description Set_Merge_Word_Cnt_Trig_RTx sets the value for the Word Count Trigger in Merge Mode. It must be set prior to calls to:

Set_Merge_Intr_Cond_RTx on page 3-30

or

Set_Merge_Trig_Cond_RTx on page 3-31

Syntax Set_Merge_Word_Cnt_Trig_RTx (int handle, uint count)

Input Parameters handle The handle designated by Init_Module_RTx.
count The count which causes the trigger

Output Parameters none

Return Values ebadhandle If handle other than the one returned by Init_Module_RTx is used.
0 If successful

Setup_Merge_Mode_RTx

Description	Setup_Merge_Mode_RTx sets the module to receive in Merge Storage Mode. Set_Merge_Mode_RTx must be called if the storage mode is set to Merge Storage Mode in Set_Global_Storage_Mode_RTx. A common storage area is set up for all ARINC receive channels in the active module. The area is large enough to contain the number of 32-bit ARINC 429 Data Words specified by num_data_words together with the associated Time Tags and Status Words. Note: Setup_Receive_Channel_RTx must be called for each of the individual active receive channels whose outputs are to be merged together.	
Syntax	Setup_Merge_Mode_RTx (int handle, uint num_data_words, uint wrap_around)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	num_data_words	The number of 32-bit ARINC 429 Data Words the buffer must hold.
	wrap_around	WRAP_AROUND
		If data should wrap around to the top of the buffer when the buffer has been filled [0 H] NO_WRAP_AROUND reception will stop when the receive area is full; the flag STOP_ON_BUFFER_FULL will be set in the Channel Status [40 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	mem_Setup_Merge_Mode	If the memory allocation failed
	0	If successful

Look-up Table Storage Mode Functions

Look-up Table Storage Mode is a submode available in Standard Storage Mode. For more information, see **Receive Channel Overview** on page 3-2.

Enable_Lkup_Table_RTx

Description	Enable_Lkup_Table_RTx sets the channel to work in Look-up Table Mode. In this mode only the most recent data associated with each label selected by Enter_Lkup_Entry_RTx is kept. This mode is used when the most recent value of each label is needed and the sequence of labels is unimportant. Following a call to this function, Enter_Lkup_Entry_RTx must be called to fill in the Look-up Table.	
Syntax	Enable_Lkup_Table_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Enable_Lkup_Table	If an invalid parameter was used as an input
	mem_Enable_Lkup_Table	If the memory allocation failed
	mode_Enable_Lkup_Table	If in receive Data Only Storage Mode
	0	If successful

Enter_Lkup_Entry_RTx

Description	Enter_Lkup_Entry_RTx allocates space for the selected label.	
Syntax	Enter_Lkup_Entry_RTx (int handle, uint channel, unsigned char label, uint intr)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	label	The label being set up
	intr	INTERRUPT Causes an interrupt to be generated by the module when this label is received [8000 H] LABEL_RECEIVED Appears in the Channel Status when the specified label is received [4 H]; if Set_Interrupt_Cond_RTx, page 3-21 or Set_Trigger_Cond_RTx, page 3-24 are called with LABEL_RECEIVED, an interrupt is issued on this condition NO_INTERRUPT Cancels the interrupt process [0 H]
	Output Parameters	none
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Enter_Lkup_Entry	If an invalid parameter was used as an input
	mem_Enter_Lkup_Entry	If the memory allocation failed
	0	If successful

Read_Lkup_Current_Lbl_RTx

Description	Read_Lkup_Current_Lbl_RTx returns the Look-up Table Current Pointer.	
Syntax	Read_Lkup_Current_Lbl_RTx (int handle, uint channel, uchar *label)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	label	The current label

Read_Lkup_Current_Lbl_RTx (cont.)

Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>param_Read_Lkup_Current_Label</code>	If an invalid parameter was used as an input
	<code>0</code>	If successful

Read_Lkup_Data_RTx

Description	Read_Lkup_Data_RTx copies the contents of the Receiver Data Block for the specified channel and label to the array pointed to by a message pointer.	
	The Receiver Data Block consists of a: • 32-bit ARINC 429 Data Word • 32-bit Time Tag • 16-bit received error count • 16-bit Status Word	
Syntax	Read_Lkup_Data_RTx (int handle, uint channel, unsigned char label, uint *msgptr)	
Input Parameters	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .
	<code>channel</code>	The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.
	<code>label</code>	The label being read
Output Parameters	<code>msgptr</code>	The data returned. See Appendix A: Data Configuration Returned by Read Data and Load Message Functions.
Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>param_Read_Lkup_Data</code>	If an invalid parameter was used as an input
	<code>lkup_data_invalid</code>	If the Look-up Table data is invalid
	<code>0</code>	If successful

4 ARINC 429 Transmit Channels Functions

Chapter 4 describes the functions to set and operate ARINC transmit channels on *429RTx[D]* modules and cards.

The following functions are described in this chapter:

General Transmit Functions

- Allocate_Message_RT_x
- Load_FrequencyMessage_RT_x
- Load_Message_RT_x
- Read_Channel_Status_RT_x
- Read_Tx_Loop_Cnt_RT_x
- Read_Tx_Total_Words_Sent_RT_x
- Set_Interrupt_Cond_RT_x
- Set_Skip_Message_RT_x
- Set_Transmit_Loop_Counter_RT_x
- Set_Transmit_Message_Once_RT_x
- Set_Trigger_Cond_RT_x
- Setup_Frame_RT_x
- Setup_Transmit_Channel_RT_x

FIFO Mode Functions

- Allocate_MAX_Transmit_FIFOs_RT_x
- Allocate_Transmit_FIFO_RT_x
- Load_Transmit_FIFO_RT_x
- Set_Transmit_FIFO_Size_RT_x

Data Reconstructor Mode (Time Tag Mode) Functions

- Add_TTAG_Data_RT_x
- Setup_Ttag_Mode_RT_x

Note: For the *DAS-429PMC/RTx* board, the software relates to channels 0–9 as module 0; channels 10–19 as module 1.
For the *DAS-429[cc]PMC/RTxD* board, the software relates to channels 0–9 as module 0; channels 10–14 as module 1.

Transmit Channel Overview

There are several modes that can be used for transmit channels that will determine the timing method with which the data will be transmitted. This section describes each mode. The next section, **Transmit Channel Setup** on page 4-4, provides details on how to set up each mode.

Three of the modes, Interblock Gap Mode, Data Rate Mode and FIFO Mode are selected via the `tx_mode` parameter of `Setup_Transmit_Channel_RTx`. The fourth mode, Data Reconstructor Mode (also called Time Tag Mode), is selected by calling `Setup_Ttag_Mode_RTx` after calling `Setup_Transmit_Channel_RTx`.

- **Interblock Gap Mode** – In this mode, you define blocks of ARINC 429 labels to be transmitted consecutively. You define the number of labels in each block, the number of bit times to wait between the transmission of labels within the block, and the amount of time to wait between the transmitting of one block to the next. All defined blocks form a frame, and the frame is transmitted the number of times specified in `Setup_Transmit_Channel_RTx`.
- **Data Rate Mode** – In this mode, you set up blocks of data and define the number of labels in each block and the number of bit times to wait between transmission of labels within the block. However, in this mode you select how often the block will be transmitted.

For example, you can request Block 1 be sent every 20 msec. and block 2 every 50 msec. In this case, the blocks would be sent as follows:

Time in Milliseconds	Data Sent
0	Blocks 1 and 2
20	Block 1
40	Block 1
50	Block 2
60	Block 1
80	Block 1
100	Blocks 1 and 2

- **FIFO Mode** – In this mode, multiple buffers (called FIFOs) can be set up for each channel. Each buffer contains labels that will be transmitted at a selected data rate. For example, if a buffer containing ten labels is setup to be transmitted every 100 msec., the first label in the buffer will be transmitted following a call to `Start_Channel_RTx`, and the next label in the buffer will be sent after 100 msec., the third after 200 msec., and so on.

When the end of the buffer is reached, the module will continue transmission with data from the beginning of the buffer. You should make the buffer large enough to guarantee the application will have time to refill the buffer before it is emptied. This mode is used when you know in advance what data is to be transmitted for an extended period of time. This can be useful for file transmission.

- **Data Reconstructor Mode** – Data Reconstructor Mode (also called Time Tag Mode) is for retransmitting previously recorded labels with the same timing as the original transmission. This mode is primarily for debug purposes. In this mode, no blocks are defined. The structure used to determine the order of transmission of labels is the same as the structure used for receive channels. That is, it is comprised of 5 16-bit words per label as follows:

Word	Description
Word 1	High word of data to be sent
Word 2	Low word of data to be sent
Word 3	High word of time tag to be sent
Word 4	Low word of Time Tag to be sent
Word 5	Status of word to be sent

In this mode, the module transmits the first label in memory when `Start_Channel_RTx` is called, the next label is transmitted based on the gap between the Time Tag of the first label and the Time Tag of the second label. For example, if the first label has a Time Tag of 1,705,000 and the second label has a Time Tag of 1,705,200 then the first label is sent out immediately upon start and the second label is sent 200 Time Tag units later, which is 2000 μ sec. or 2 msec. Succeeding labels are sent based on their Time Tags in order to match the timing of the original transmission.

When the end of the buffer is reached, the firmware wraps around to the beginning of the buffer. The `flag` parameter of `Setup_Ttag_Mode_RTx` determines what the module does at this point.

If the recording is small enough to fit into the module's memory, you have the option of settings the `flag` parameter to `TTAGBASEDLOOP`, and the labels will be transmitted continuously in a loop.

If the previous recording is too long to fit into the module's memory, you should not use the `TTAGBASEDLOOP` value for the `flag` parameter. You should set the `flag` parameter to 0, and when the end of the buffer is reached, the firmware will wrap around to the beginning of the buffer and wait for the first label's Time Tag to be greater than the Time Tag of the previously transmitted label, i.e., the one at the end of the buffer. In this case, your program must call `Add_TTAG_Data_RTx` periodically to reload the module's memory with new labels as the old labels are transmitted.

Transmit Channel Setup

To set up transmit channels in Interblock Gap Mode or Data Rate Mode, call:

1. Init_Module_RT_x to initialize the module. page 2-4
1. Setup_Transmit_Channel_RT_x to set up a transmit channel transmission. page 4-19
2. Allocate_Message_RT_x to allocate a unique message number in the message stack. page 4-6
3. Load_Message_RT_x or Load_FrequencyMessage_RT_x to load data to be transmitted. page 4-9
4. (Optional) Set_Skip_Message_RT_x to skip a specific message and transmit it only on demand. page 4-14
5. (Optional) Set_Interrupt_Cond_RT_x or Set_Trigger_Cond_RT_x to work with interrupts and/or external triggers. page 4-13 and page 4-17
6. Start_Channel_RT_x or Start_Selected_Channels_RT_x after all the channels are set up. page 2-17
7. (Optional) Set_Transmit_Message_Once_RT_x to transmit a message once. page 4-16

To set up transmit channels in FIFO Mode, call:

1. Init_Module_RT_x to initialize the module. page 2-4
1. Setup_Transmit_Channel_RT_x to set up a transmit channel transmission. page 4-19
2. Allocate_MAX_Transmit_FIFOs_RT_x to set maximum the number of different FIFOs to be used. page 4-21
3. Allocate_Transmit_FIFO_RT_x to allocate space for each FIFO to be used. page 4-22
4. Set_Transmit_FIFO_Size_RT_x to set the actual size of a particular FIFO. page 4-24
5. Load_Transmit_FIFO_RT_x to load data into the FIFO. page 4-23
6. Start_Channel_RT_x or Start_Selected_Channels_RT_x after all the channels are set up. page 2-17
7. When there is too much data to fit into the FIFO, call Load_Transmit_FIFO_RT_x periodically to load data while the data is being transmitted. page 4-23

To set up transmit channels in Data Reconstructor Mode (Time Tag Mode), call:

1. Init_Module_RT_x and set the desired channels to transmit. page 2-4
2. Setup_Transmit_Channel_RT_x to set up a transmit channel page 4-19
 transmission.
3. Setup_Ttag_Mode_RT_x to set up Data Reconstructor Mode page 4-26
 (Time Tag Mode).
4. Add_TTAG_Data_RT_x to load data to be transmitted. page 4-25
5. Start_Channel_RT_x or Start_Selected_Channels_RT_x after all the page 2-17
 channels are set up.
6. When there is too much data to fit into the module's page 4-25
 memory, call Add_TTAG_Data_RT_x periodically to load
 data while the data is being transmitted.

General Transmit Functions

General transmit functions are relevant in more than one transmit mode.

Allocate_Message_RTx

Description	Allocate_Message_RTx allocates a message in the message stack. A message consists of 1 – 255 ARINC words that are transmitted consecutively and with the same interword gap time. Each message is given a message number. For each channel, the first message is message number 1. The message numbers increment by 1 for subsequent messages. For each call to this function, a call must be made to Load_Message_RTx on page 4-9, using the allocated message number. You can allocate multiple messages by calling this function (and Load_Message_RTx) multiple times. For details on memory size, see Memory Usage Limits on page 3-2. A call to Setup_Transmit_Channel_RTx on page 4-19, clears the message stack and message numbers.	
Syntax	Allocate_Message_RTx (int handle, uint channel, uint max_msg_size)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	max_msg_size	Number of ARINC words in the message
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Allocate_Message	If an invalid parameter was used as an input
	mem_Allocate_Message	If the memory allocation failed
	msg_Allocate_Message	If there are too many calls to this function; Too many calls to Allocate_Message_RTx; the number of messages cannot exceed max_messages in Setup_Transmit_Channel_RTx
	<number of the new message allocated>	If successful, returns the number of the new message allocated

Load_FrequencyMessage_RTx

Description	Load_FrequencyMessage_RTx loads a message previously allocated by Allocate_Message_RTx on page 4-6. This function defines the number of labels in the message and its timing characteristics including how frequently the message will be transmitted, how much time between transmission of labels within the message and how long after the start of the channel will the first label in the message be transmitted. Note: This function is only available with firmware revision 3.9 or later.	
Syntax	Load_FrequencyMessage_RTx (int handle, uint channel, uint msg_num, uint err_inj, uint word_cnt, uint interword_dly, uint frequency, uint offset, uint *msgptr)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	msg_num	Message number of a message created by Allocate_Message_RTx
	err_inj	Error injection – one or more of the following flags: NO_ERROR_429 No error injection [0 H] PARITY_429_ERROR Incorrect parity inserted in every word message [1 H] NULL_BIT_ERROR null bit error inserted in ARINC bit 02 of every word in message [2 H] STRETCH_BIT_ERROR ARINC bit 02 of every word is stretched causing a Manchester coding error [4 H] BIT_CNT_HI_ERROR Every word in message transmitted with 33 bits [8 H] BIT_CNT_LO_ERROR Every word in message transmitted with 31 bits [10 H] SUPPRESS_PARITY_ERROR Forces no parity condition on every word in message [20 H]

Load_FrequencyMessage_RTx (cont.)

	word_cnt	Number of 32-bit ARINC 429 Data Words in a message. This number of words will be copied from the specified array to the module's/card's memory. This value must be less than or equal to the parameter <code>max_msg_size</code> passed to Allocate_Message_RTx on page 4-6.
	interword_dly	Number of bit times inserted between consecutive words within the message. Allowed values are 0 – 255. 4 is the minimum legal value according to the ARINC 429 specification.
	frequency	How much time to wait between transmissions of the message. If <code>Setup_Transmit_Channel_RTx</code> was called with <code>EXTENDED_TIME_ENABLE</code> , the <code>frequency</code> is in milliseconds with a range of 1 to 1310. Otherwise, it is in bit times with a range of 1 to 65,535. For example, to transmit a high speed message every 40 milliseconds, set this value to 4000.
	offset	How long to wait for the first transmission following start of the channel. To load balance, divide the labels from a single frequency into N parts and adjust the offset by <code>frequency/N</code> for each message. For example, if you need to transmit 20 labels every 40 milliseconds, you can have 4 messages of 5 labels, all having a frequency of 4000 and the offsets 0 for Message 0, 1000 for Message 1, 2000 for Message 2 and 3000 for Message 3.
	msgptr	This is the pointer to an integer array containing the 32-bit ARINC 429 Data Words to be loaded.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	esetuptxchan	If <code>Setup_Transmit_Channel_RTx</code> was not called for this channel
	eenhancedfrequencynotsupported	If the firmware on this module does not support this Enhanced Frequency function
	msg_num_Load_Message	If <code>msg_num</code> is invalid; was not returned by a call to <code>Allocate_Message_RTx</code>
	enotdata rate mode	If <code>Setup_Transmit_Channel_RTx</code> did not set this channel to be in <code>DATA_RATE_MODE</code>

Load_FrequencyMessage_RTx (cont.)

param_Load_	If the channel does not exist on the board
_Message	
param_Load_	If word_cnt is greater than 255 or 0
Message1	
param_Load_	If interword_dly is greater than 255
Message2	
param_Load_	If Setup_Transmit_Channel_RTx specifies
Message3	EXTENDED_TIME_ENABLE and frequency
	is greater than 1310 or less than 1
param_Load_	If Setup_Transmit_Channel_RTx did not specify
Message4	EXTENDED_TIME_ENABLE and frequency
	is greater than 65535 (FFFF H) or less than 0
param_Load_	If there is not enough space left on the module
Message5	for word_cnt words
0	If successful

Load_Message_RTx**Description**

Load_Message_RTx copies data from an array to a message in the message stack. This function must be called at least once for each message allocated by **Allocate_Message_RTx** on page 4-6. The function can be called periodically while the channel is running, to change a message in real time.

Note: In Data Rate Mode, you can also use Load_FrequencyMessage_RTx, which allows you to select the start of message transmission, relative to other Data Rate Mode messages. See **Load_FrequencyMessage_RTx** on page 4-7.

Syntax

Load_Message_RTx (int handle, uint channel, uint msg_num, uint err_inj, uint word_cnt, uint interword_dly, uint intermsg_rate, uint *msgptr)

Input Parameters

handle	The handle designated by Init_Module_RTx.
channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
msg_num	Message number of a message created by Allocate_Message_RTx
err_inj	Error injection – one or more of the following flags: NO_ERROR_429 No error injection [0 H]

Load_Message_RTx (cont.)

	PARITY_429_ERROR Incorrect parity inserted in every word message [1 H]
	NULL_BIT_ERROR null bit error inserted in ARINC bit 02 of every word in message [2 H]
	STRETCH_BIT_ERROR ARINC bit 02 of every word is stretched causing a Manchester coding error [4 H]
	BIT_CNT_HI_ERROR Every word in message transmitted with 33 bits [8 H]
	BIT_CNT_LO_ERROR Every word in message transmitted with 31 bits [10 H]
	SUPPRESS_PARITY_ERROR Forces no parity condition on every word in message [20 H]
word_cnt	Number of 32-bit ARINC 429 Data Words in a message. This number of words will be copied from the specified array to the module's/card's memory. This value must be less than or equal to the parameter max_msg_size passed to Allocate_Message_RTx on page 4-6.
interword_dly	Number of bit times inserted between consecutive words within the message. Allowed values are 0 – 255.
intermsg_rate	In INTERBLOCK_GAP_MODE , this specifies the number of bit times to be inserted between this message and the next one. Allowed values are 0-65535. If Extended Time is enabled on the channel, this value is in msec. and the allowed values are 1 – 1300 when using a high bit rate, and 8 – 10480 when using a low bit rate. See Setup_Transmit_Channel_RTx on page 4-19. In DATA_RATE_MODE , this specifies the period of the message in bit times (if the value is <i>n</i> the message is transmitted every <i>n</i> bit times).
msgptr	This is the pointer to an integer array containing the 32-bit ARINC 429 Data Words to be loaded.

Load_Message_RTx (cont.)**Output Parameters** none

Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	esetuptxchan	If Setup_Transmit_Channel_RTx was not called for this channel
	msg_num_Load_Message	If msg_num is invalid; was not returned by a call to Allocate_Message_RTx
	param_Load_Message	If the channel does not exist on the board
	param_Load_Message1	If word_cnt is greater than 255 or 0
	param_Load_Message2	If interword_dly is greater than 255
	param_Load_Message3	If Setup_Transmit_Channel_RTx specifies EXTENDED_TIME_ENABLE and intermsg_rate is greater than 1310 or less than 1
	param_Load_Message4	If Setup_Transmit_Channel_RTx did not specify EXTENDED_TIME_ENABLE and intermsg_rate is greater than 65535 (FFFF H) or less than 0
	param_Load_Message5	If there is not enough space left on the module for word_cnt words
	0	If successful

Read_Channel_Status_RTx

Description Read_Channel_Status_RTx returns and clears the status of the specific channel.

Syntax Read_Channel_Status_RTx (int handle, uint channel)

Input Parameters

handle	The handle designated by Init_Module_RTx.
channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.

Output Parameters none

Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Channel_Status	If an invalid parameter was used as an input

Read_Channel_Status_RTx (cont.)

<status of the channel>	If successful, returns the status of the channel: TX_END_OF_BLOCK Set when a transmit channel has completed transmission of a block (message) [1 H] TX_END_OF_FRAME Set when a transmit channel has completed transmission of an entire stack of blocks (messages) [2 H]
-------------------------	--

Read_Tx_Loop_Cnt_RTx

Description	Read_Tx_Loop_Cnt_RTx reads the current transmit loop register. This quantity counts down from its initial value set in Setup_Transmit_Channel_RTx until it reaches 1.	
Syntax	Read_Tx_Loop_Cnt_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Read_Tx_Loop_Cnt	If an invalid parameter was used as an input
	<number of loops left to send>	If successful, returns the number of loops left to send

Read_Tx_Total_Words_Sent_RTx

Description	Read_Tx_Total_Words_Sent_RTx reads the total number of words sent. Note: This is a 16-bit counter, which returns to 0 after reaching 65,535.	
Syntax	Read_Tx_Total_Words_Sent_RTx (int handle, uint channel)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
Output Parameters	none	

Read_Tx_Total_Words_Sent_RTx (cont.)

Return Values	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.
	<code>param_Read_Tx_Total_Words_Sent</code>	If an invalid parameter was used as an input
	<code><number of words sent></code>	If successful, returns the total number of words sent

Set_Interrupt_Cond_RTx

Description	Set_Interrupt_Cond_RTx sets the condition or conditions for which the specified channel issues an interrupt. The default is for no interrupts to be issued.	
Syntax	Set_Interrupt_Cond_RTx (int handle, uint channel, uint condition)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	condition	TX_END_OF_BLOCK An entire block (message) has been transmitted [1 H]
		TX_END_OF_FRAME An entire frame (stack of messages) has been transmitted [2 H]
NO_INTERRUPTS Cancels interrupts [0 H]		
Output Parameters	none	
	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Interrupt_Cond	If an invalid parameter was used as an input
	0	If successful

Set_Skip_Message_RTx

Description	Set_Skip_Message_RTx causes a message that has been loaded by Load_Message_RTx not to be transmitted. All other messages will be transmitted as scheduled.	
	Note: This function is only available with firmware revision 1.47 or later.	
Syntax	Set_Skip_Message_RTx (int handle, uint channel, uint msg_num, uint skip_flag)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel over which the message was supposed to be transmitted, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	msg_num	Message number used by Load_Message_RTx to load the message
	skip_flag	One of the following: SKIP_MESSAGE Skip this message [40 H] RESTORE_MESSAGE Allow the skipped message to start transmitting again as scheduled [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Skip_Message	If an invalid channel was used
	msg_num_Skip_Message	If an invalid msg_num was used
	0	If successful

Set_Transmit_Loop_Counter_RTx

Description	Set_Transmit_Loop_Counter_RTx sets the loop counter to how many times an instruction stack should be sent.	
	Note: The function should be called only when the channel is <i>not</i> running. If the function is called when the channel is running, it will not take effect. It will take effect the next time the transmit channel is started.	
Syntax	Set_Transmit_Loop_Counter_RTx (int handle, uint channel, uint loop_cntr)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	loop_cntr	CONTINUOUS Transmit message stack continuously [0 H] 1 – 65535 Transmit message stack this number of times
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_tx_chan	If not an ARINC transmit channel
	0	If successful

Set_Transmit_Message_Once_RTx

Description	Set_Transmit_Message_Once_RTx causes a message that was set to be skipped, to be transmitted once, after which the firmware returns it to be skipped. This allows you to send asynchronous messages. To use this function, set up the message using Allocate_Message_RTx and Load_Message_RTx, set the message to be skipped using Set_Skip_Message_RTx, then call this function to transmit the message asynchronously. After the message is transmitted, the firmware sets the message back to being skipped. When is this asynchronous message transmitted? In Interblock Gap Mode, the message will be transmitted when the appropriate block is called (in sequence). In Data Rate Mode, the message will be transmitted according to its frequency, relative to the last Time Tag of this message. Hence, this is the appropriate method for transmitting the message immediately. The frequency should be set to the smallest interval this message might be transmitted. For example, if this message will be sent at least 65 milliseconds apart, set its frequency to 65 milliseconds. If this message might be sent one millisecond apart, set its frequency to one millisecond. Note: This function is only available with firmware revision 2.7 and later.
Syntax	Set_Transmit_Message_Once_RTx (int handle, uint channel, uint msg_num)
Input Parameters	handle The handle designated by Init_Module_RTx. channel The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10. msg_num Message number of a message created by Allocate_Message_RTx
Output Parameters	none
Return Values	ebadhandle If handle other than the one returned by Init_Module_RTx is used. efeature_not_supported_RTx If feature is not supported on this module param_Skip_Message If an invalid channel was used

Set_Transmit_Message_Once_RTx (cont.)

esetuptxchan	If Setup_Transmit_Channel_RTx was not called for this channel
msg_num_ Skip_Message	If an invalid msg_num was used
0	If successful

Set_Trigger_Cond_RTx

Description	Set_Trigger_Cond_RTx sets the condition or conditions under which the specified channel issues a trigger. The default is for no triggers to be issued.	
Syntax	Set_Trigger_Cond_RTx (int handle, uint channel, uint condition)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	condition	TX_END_OF_BLOCK An entire block (message) has been transmitted [1 H]
		TX_END_OF_FRAME An entire frame (stack of messages) has been transmitted [2 H]
		NO_TRIGGER Cancels triggers [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	param_Set_Trigger_Cond	If an invalid parameter was used as an input
	0	If successful

Setup_Frame_RTx

Description	Setup_Frame_RTx sets up a frame. The user indicates which message to begin transmitting and how many messages in the stack to transmit.	
Syntax	Setup_Frame_RTx (int handle, uint channel, uint begin_message, uint end_message)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	begin_message	Message number of first message to transmit Valid values: 1 – number of messages loaded <i>or</i> FIRST_MESSAGE Start from the first message allocated [1 H]
	end_message	Message number of last message to transmit Valid values: 1 – number of messages loaded <i>or</i> LAST_MESSAGE Transmit until the last message allocated [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	bad_tx_chan	If not an ARINC transmit channel
	bad_param	If an invalid parameter was used as an input
	0	If successful

Setup_Transmit_Channel_RTx

Description	Setup_Transmit_Channel_RTx is the first function to call to set up and operate the ARINC transmit channels.		
	The Setup_Transmit_Channel_RTx function can only be set when all the channels are turned off via the Stop_Channel_RTx/ Stop_Discrete_RTD functions. The card/module should be started via the Start_Channel_RTx/Start_Discrete_RTD functions only after a minimum of 1 msec. from the time that the contents of the function have been changed.		
	Note: For boards with Discrete channels, the ARINC 429 channels are set independently from the Discrete channels. Therefore:		
	• Use Start/Stop_Channel_RTx when setting the ARINC channels. • Use Start/Stop_Discrete_RTD when setting the Discrete channels.		
Syntax	Setup_Transmit_Channel_RTx (int handle, uint channel, uint config, uint max_messages, uint loop_cntr)		
Input Parameters	handle	The handle designated by Init_Module_RTx.	
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.	
	config	Combination of 1 flag from each of the relevant groups:	
	bit_rate	EXC_BIT_RATE_LO	12.5 KHz [0 H]
		EXC_BIT_RATE_HI	100 KHz [1 H]
		BIT_RATE_PROG	bit rate as set in Set_Prog_Bit_Rate_RTx on page 2-14 [2 H]
	parity	AR_PARITY_ODD	odd parity [0 H]
		AR_PARITY_EVEN	even parity [10 H]
		AR_PARITY_OFF	no parity [8 H]
	tx_mode	INTERBLOCK_GAP_MODE	
		Send each message with a specified delay between messages (default mode) [0 H]	
		DATA_RATE_MODE	
		Send each message according to the specified rate [100 H]	
		FIFO_DATA_MODE	
		Set up FIFO buffers for each channel [1000 H]	
		Note: For Data Reconstructor Mode (Time Tag Mode), use any of the above values for tx_mode, then call Setup_Ttag_Mode_RTx.	

Setup_Transmit_Channel_RTx (cont.)

		tx_rise	RISE_HI_SPEED tx rise/fall time 1.5+/-0.5 μ sec. [0 H] (default value; for hi speed bit rate, a hi speed rise/fall time must be selected.) RISE_LO_SPEED tx rise/fall time 10+/-5 μ sec. [4 H]
		ext_time	EXTENDED_TIME_ENABLE Extended Time is enabled on the channel [400 H]; this feature increases the transmit timing (see Load_Message_RTx on page 4-9) Note: This bit is only relevant when using INTERBLOCK_GAP_MODE for the tx_mode parameter, and Extended Time is supported by the firmware. See Read_Board_Status_RTx on page 2-7.
			EXTENDED_TIME_DISABLE Extended Time is disabled on the channel (default) [0 H]
		max_messages	The maximum number of messages to be defined in the instruction stack
		loop_cntr	Number of times to transmit an entire stack. CONTINUOUS Transmit message stack continuously [0 H] 1 – 65535 Transmit message stack this number of times
			Note: When using DATA_RATE_MODE or FIFO_DATA_MODE for the tx_mode parameter, the loop_cntr parameter is ignored and the message is transmitted continuously. See tx_mode on page 4-19.
	Output Parameters Return Values	none	
		ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
		param_Setup_Transmit_Channel	If the parameter is out of range
		mem_Setup_Transmit_Channel	If the memory allocation failed
		bad_tx_chan	If not an ARINC transmit channel
		eboardstarted	If cannot change communication parameters
		no_extended_time_support	If Extended Time is enabled on the channel but not supported by the firmware
		0	If successful

FIFO Mode Functions

Allocate_MAX_Transmit_FIFOs_RTx

Description	Allocate_MAX_Transmit_FIFOs_RTx allocates memory for a table of pointers to FIFOs for the selected channel. The memory allocation for the FIFOs themselves is done by calling Allocate_Transmit_FIFO_RTx. Allocate_MAX_Transmit_FIFOs_RTx must be called before any calls to Allocate_Transmit_FIFO_RTx. The numFIFOs parameter determines the maximum number of times Allocate_Transmit_FIFO_RTx can be called for that channel. Note: This function is only available with firmware revision 2.4 or later.	
Syntax	Allocate_MAX_Transmit_FIFOs_RTx (int handle, usint channel, usint numFIFOs)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	numFIFOs	The maximum number of FIFOs that can be allocated for this channel.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Allocate_Transmit_FIFO_RTx

Description	Allocate_Transmit_FIFO_RTx allocates memory for a FIFO for the selected channel. Labels associated with a particular FIFO will be transmitted at a rate of one label every ‘frequency’ μsec. The <code>FIFOmaxSize</code> parameter sets the maximum number of labels that can be stored in the FIFO using <code>Load_Transmit_FIFO_RTx</code>. For example, if <code>Allocate_Transmit_FIFO_RTx</code> is called with <code>FIFOmaxSize = 10</code> and <code>frequency = 50000</code>, you can then load 10 labels using <code>Load_Transmit_FIFO_RTx</code> and they will be sent out at times 0, 50000 μsec., 100000 μsec., etc., until the final label is sent at 450,000 μsec. (450 msec.). You can call <code>Load_Transmit_FIFO_RTx</code> during this transmission to top off the FIFO, and the transmission will continue as long as fresh data is available. Note: • <code>Allocate_MAX_Transmit_FIFOs_RTx</code> must be called before calling this function. • This function is only available with firmware revision 2.4 or later.										
Syntax	<code>Allocate_Transmit_FIFO_RTx (int handle, uint channel, int FIFOnumber, int FIFOmaxSize, int frequency)</code>										
Input Parameters	<table> <tr> <td data-bbox="597 1123 792 1150"><code>handle</code></td><td data-bbox="808 1123 1442 1150">The handle designated by <code>Init_Module_RTx</code>.</td></tr> <tr> <td data-bbox="597 1165 792 1192"><code>channel</code></td><td data-bbox="808 1165 1442 1270">The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.</td></tr> <tr> <td data-bbox="597 1285 792 1312"><code>FIFOnumber</code></td><td data-bbox="808 1285 1442 1501"> The ID number to assign to this FIFO. This number is used when loading data into the FIFO via <code>Load_Transmit_FIFO_RTx</code>. The valid range is 0 to <code>numFIFOs-1</code>. (<code>numFIFOs</code> is the last parameter in <code>Allocate_MAX_Transmit_FIFOs_RTx</code>.) </td></tr> <tr> <td data-bbox="597 1516 792 1543"><code>FIFOmaxSize</code></td><td data-bbox="808 1516 1442 1585">The maximum number of labels that can be stored in this FIFO.</td></tr> <tr> <td data-bbox="597 1600 792 1627"><code>frequency</code></td><td data-bbox="808 1600 1442 1696">The number of μsec. between the start of one label’s transmission until the start of the next label’s transmission.</td></tr> </table>	<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .	<code>channel</code>	The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.	<code>FIFOnumber</code>	The ID number to assign to this FIFO. This number is used when loading data into the FIFO via <code>Load_Transmit_FIFO_RTx</code>. The valid range is 0 to <code>numFIFOs-1</code>. (<code>numFIFOs</code> is the last parameter in <code>Allocate_MAX_Transmit_FIFOs_RTx</code>.)	<code>FIFOmaxSize</code>	The maximum number of labels that can be stored in this FIFO.	<code>frequency</code>	The number of μ sec. between the start of one label’s transmission until the start of the next label’s transmission.
<code>handle</code>	The handle designated by <code>Init_Module_RTx</code> .										
<code>channel</code>	The channel value, 0 – 9, depending on the board or module. See <code>Read_Number_Of_Channels_RTx</code> on page 2-10.										
<code>FIFOnumber</code>	The ID number to assign to this FIFO. This number is used when loading data into the FIFO via <code>Load_Transmit_FIFO_RTx</code>. The valid range is 0 to <code>numFIFOs-1</code>. (<code>numFIFOs</code> is the last parameter in <code>Allocate_MAX_Transmit_FIFOs_RTx</code>.)										
<code>FIFOmaxSize</code>	The maximum number of labels that can be stored in this FIFO.										
<code>frequency</code>	The number of μ sec. between the start of one label’s transmission until the start of the next label’s transmission.										
Return Values	<table> <tr> <td data-bbox="597 1711 792 1738"><code>ebadhandle</code></td><td data-bbox="808 1711 1442 1780">If handle other than the one returned by <code>Init_Module_RTx</code> is used.</td></tr> <tr> <td data-bbox="597 1795 792 1822">0</td><td data-bbox="808 1795 1442 1822">If successful</td></tr> </table>	<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.	0	If successful						
<code>ebadhandle</code>	If handle other than the one returned by <code>Init_Module_RTx</code> is used.										
0	If successful										

Load_Transmit_FIFO_RTx

Description	Load_Transmit_FIFO_RTx loads one or more words into a FIFO previously allocated by calling Allocate_Transmit_FIFO_RTx. If your application is constantly loading data to the FIFO, you generally do not want the application to wait for the FIFO to be empty before loading data, since this would harm the transmission timing. To help avoid the FIFO being empty when loading data, this function has two output parameters, <code>actualLoaded</code> and <code>actualStartIndex</code>, that enable you to calculate how full the FIFO was at the time the data was loaded. Note: • You must call Set_Transmit_FIFO_Size_RTx before calling this function. • This function is only available with firmware revision 2.4 or later.								
Syntax	Load_Transmit_FIFO_RTx (int handle, uint channel, int FIFOnumber, struct FIFO_DATA_CONTROL *data, int numWords, int *actualLoaded, int *actualStartIndex)								
Input Parameters	<table> <tr> <td data-bbox="597 934 722 966">handle</td><td data-bbox="824 934 1455 966">The handle designated by Init_Module_RTx.</td></tr> <tr> <td data-bbox="597 976 722 1008">channel</td><td data-bbox="824 976 1455 1081">The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.</td></tr> <tr> <td data-bbox="597 1092 771 1123">FIFOnumber</td><td data-bbox="824 1092 1455 1186">The ID number of the desired FIFO. This number was assigned when calling Allocate_Transmit_FIFO_RTx.</td></tr> <tr> <td data-bbox="597 1197 673 1228">data</td><td data-bbox="824 1197 1455 1228">A pointer to a structure of type:</td></tr> </table> <pre> struct FIFO_DATA_CONTROL { int control; //error injection associated with the 'data' in this //entry; see note below int data; //ARINC 429 Data Word }; </pre> Note: For error injection options, see the <code>err_inj</code> parameter of Load_Message_RTx on page 4-9.	handle	The handle designated by Init_Module_RTx.	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.	FIFOnumber	The ID number of the desired FIFO. This number was assigned when calling Allocate_Transmit_FIFO_RTx.	data	A pointer to a structure of type:
handle	The handle designated by Init_Module_RTx.								
channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.								
FIFOnumber	The ID number of the desired FIFO. This number was assigned when calling Allocate_Transmit_FIFO_RTx.								
data	A pointer to a structure of type:								
Output Parameters	<table> <tr> <td data-bbox="597 1480 738 1512">numWords</td><td data-bbox="824 1480 1455 1543">The number of entries within the structure pointed to by <code>data</code> that the user has filled in.</td></tr> <tr> <td data-bbox="597 1554 803 1585">actualLoaded</td><td data-bbox="824 1554 1455 1873"> A pointer to an integer that will be filled in by this function with the actual number of words loaded into the FIFO. This may be fewer than <code>numWords</code> if <code>numWords</code> is greater than the <code>FIFOsize</code> parameter of Set_Transmit_FIFO_Size_RTx or if the FIFO still contains unused data and does not have enough room for <code>numWords</code> additional words. </td></tr> </table>	numWords	The number of entries within the structure pointed to by <code>data</code> that the user has filled in.	actualLoaded	A pointer to an integer that will be filled in by this function with the actual number of words loaded into the FIFO. This may be fewer than <code>numWords</code> if <code>numWords</code> is greater than the <code>FIFOsize</code> parameter of Set_Transmit_FIFO_Size_RTx or if the FIFO still contains unused data and does not have enough room for <code>numWords</code> additional words.				
numWords	The number of entries within the structure pointed to by <code>data</code> that the user has filled in.								
actualLoaded	A pointer to an integer that will be filled in by this function with the actual number of words loaded into the FIFO. This may be fewer than <code>numWords</code> if <code>numWords</code> is greater than the <code>FIFOsize</code> parameter of Set_Transmit_FIFO_Size_RTx or if the FIFO still contains unused data and does not have enough room for <code>numWords</code> additional words.								

Load_Transmit_FIFO_RTx (cont.)

	actualStartIndex	A pointer to an integer that will be filled in by this function. The integer is the index in the FIFO that was loaded with the first Data Word in data structure.
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Set_Transmit_FIFO_Size_RTx

Description	Set_Transmit_FIFO_Size_RTx determines the number of labels to be stored in the FIFO. This number cannot be greater than the FIFOsize parameter that was set when Allocate_Transmit_FIFO_RTx was called. When this number of labels is loaded into the FIFO, Load_Transmit_FIFO_RTx wraps around to the beginning of the FIFO. This functions allows you to allocate the maximum size when creating the FIFO (Allocate_Transmit_FIFO_RTx) and decide later how large of a FIFO you want to actually use. You can call Set_Transmit_FIFO_Size_RTx later in your program to change the size of FIFO, as long as it is not larger than FIFOsize. Note: This function is only available with firmware revision 2.4 or later.	
Syntax	Set_Transmit_FIFO_Size_RTx (int handle, uint channel, int FIFOnumber, int FIFOsize)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	channel	The channel value, 0 – 9, depending on the board or module. See Read_Number_Of_Channels_RTx on page 2-10.
	FIFOnumber	The ID number of the desired FIFO. This number was assigned when calling Allocate_Transmit_FIFO_RTx.
	FIFOsize	The actual number of labels to be stored in the FIFO before Load_Transmit_FIFO_RTx wraps around to the beginning of the FIFO.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

Data Reconstructor Mode Functions

The following functions are used in Data Reconstructor Mode (also called Time Tag Mode). This mode reconstructs received data and transmits it on the ARINC 429 bus. The data transmission is synchronized based on the Time Tags of the received messages. You can also use the *Data Reconstructor 429* utility provided by Excalibur.

See **Transmit Channel Overview** on page 4-2 for details on using this mode and see **Transmit Channel Setup** on page 4-4 for the correct order to call these functions. For a sample application using these functions, see the demo program **demo_ttagxmt.c**.

Add_TTAG_Data_RTx

Description	Add_TTAG_Data_RTx adds one or more labels to transmit. Each label is accompanied by a Time Tag and a Status Word. The Time Tag determines when to transmit; the Status Word is used for data injection and to select the channel on which to transmit. Note: This function is only available with firmware revision 1.47 or later.								
Syntax	Add_TTAG_Data_RTx (int handle, struct SEQ_DATA *pSEQdata, int numlabels, int *labelsAdded)								
Input Parameters	<table border="0"> <tr> <td data-bbox="584 1039 730 1071">handle</td><td data-bbox="795 1039 1438 1071">The handle designated by Init_Module_RTx.</td></tr> <tr> <td data-bbox="584 1071 730 1102">pSEQdata</td><td data-bbox="795 1071 1438 1144">A pointer to the list of labels and data to be added to the list. The struct is as follows:</td></tr> <tr> <td colspan="2" rowspan="5"> <pre> struct SEQ_DATA{ uint DataHi; uint DataLo; uint TimeTagHi; uint TimeTagLo; uint Status; }; </pre> </td></tr> <tr></tr> <tr></tr> <tr></tr> <tr></tr> <tr> <td colspan="2"> Note: Data Words, Time Tags and Status Word are described in Appendix A: Data Configuration Returned by Read Data and Load Message Functions. </td></tr> </table>	handle	The handle designated by Init_Module_RTx.	pSEQdata	A pointer to the list of labels and data to be added to the list. The struct is as follows:	<pre> struct SEQ_DATA{ uint DataHi; uint DataLo; uint TimeTagHi; uint TimeTagLo; uint Status; }; </pre>		Note: Data Words, Time Tags and Status Word are described in Appendix A: Data Configuration Returned by Read Data and Load Message Functions.	
handle	The handle designated by Init_Module_RTx.								
pSEQdata	A pointer to the list of labels and data to be added to the list. The struct is as follows:								
<pre> struct SEQ_DATA{ uint DataHi; uint DataLo; uint TimeTagHi; uint TimeTagLo; uint Status; }; </pre>									
Note: Data Words, Time Tags and Status Word are described in Appendix A: Data Configuration Returned by Read Data and Load Message Functions.									
Output Parameters	<table border="0"> <tr> <td data-bbox="584 1543 730 1575">numlabels</td><td data-bbox="795 1543 1438 1575">The number of labels to add to the list</td></tr> <tr> <td data-bbox="584 1575 730 1606">labelsAdded</td><td data-bbox="795 1575 1438 1753">The number of labels added to the list. This will be less than numlabels if there is not enough room for numlabels new entires in the buffer. This function does not overwrite labels that have not been sent yet.</td></tr> </table>	numlabels	The number of labels to add to the list	labelsAdded	The number of labels added to the list. This will be less than numlabels if there is not enough room for numlabels new entires in the buffer. This function does not overwrite labels that have not been sent yet.				
numlabels	The number of labels to add to the list								
labelsAdded	The number of labels added to the list. This will be less than numlabels if there is not enough room for numlabels new entires in the buffer. This function does not overwrite labels that have not been sent yet.								
Return Values	<table border="0"> <tr> <td data-bbox="584 1753 730 1785">ebadhandle</td><td data-bbox="795 1753 1438 1816">If handle other than the one returned by Init_Module_RTx is used.</td></tr> <tr> <td data-bbox="584 1816 730 1862">0</td><td data-bbox="795 1816 1438 1862">If successful</td></tr> </table>	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.	0	If successful				
ebadhandle	If handle other than the one returned by Init_Module_RTx is used.								
0	If successful								

Setup_Ttag_Mode_RTx

Description	Setup_Ttag_Mode_RTx sets up the module or card to transmit previously recorded data. The user fills memory with data recorded in Merge Storage Mode of a previous run of the module/card. The format of the data is exactly the same as it was when it was recorded. The pMap parameter is an array of ten unsigned short integers used to map input to output channels. For example, to transmit all data that was received by Channel 0 over Channel 2 and to transmit all data that was received on Channel 1 over Channel 7, fill the first entries pointed to by pMap follows: <pre>pMap[0]=2; pMap[1]=7;</pre> Note: This function is only available with firmware revision 1.47 or later.	
Syntax	Setup_Ttag_Mode_RTx (int handle, uint flag, uint *pMap)	
Input Parameters	handle	The handle designated by Init_Module_RTx.
	flag	One of the following flags: TTAGBASEDLOOP The labels will be transmitted continuously in a loop [8 H] 0 When the end of the buffer is reached, the firmware will wrap around to the beginning of the buffer and wait for the first label's Time Tag to be greater than the Time Tag of the previously transmitted label, i.e., the one at the end of the buffer.
	pMap	A pointer to array containing the input to output channel mapping.
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Module_RTx is used.
	0	If successful

5 Discrete Channels Functions

Chapter 5 contains descriptions of all the functions necessary to write test programs for the Discrete channels [0–3] on modules that have both ARINC 429 and Discrete channels on the **same** module.

Note: This chapter does not apply to products that have separate ARINC 429 and Discrete modules. If you are not sure if your product has both ARINC 429 and Discrete on the same module, contact Technical Support. See **Technical Support** on page 1-8. (For working with Discretes on a separate module, see *Discrete Software Tools Programmer's Reference*.)

Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for inputs where applicable.

For card level functions, Init_Module_RTx, Release_Module_RTx and Get_Error_String_RTx see **Chapter 2 General Functions**.

To handle interrupts see **Using Interrupts Under Windows** on page 2-19.

The following functions are described in this chapter:

Get_HWid_RTD	Set_Threshold_RTD
Read_All_Input_Discretes_RTD	Set_Trigger_RTD
Read_Input_Discrete_RTD	Set_Trigger_Destination_RTD
Read_Output_Discrete_RTD	Set_Trigger_Mask_RTD
Read_Pending_RTD	Set_Trigger_Value_RTD
Read_Pending_Register_RTD	Start_Discrete_RTD
Reset_RTD	Stop_Discrete_RTD
Reset_Pending_RTD	Write_Output_Discrete_RTD
Reset_Pending_Register_RTD	

Get_HWid_RTD

Description	Get_HWid_RTD returns the hardware ID	
Syntax	Get_HWid_RTD_RTD (int handle, usint *hwid)	
Input Parameters	handle	The handle designated by Init_Card_RTx.
Output Parameters	hwid	Returns the current version of the module
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Read_All_Input_Discretes_RTD

Description	Read_All_Input_Discretes_RTD reads all input channels.	
Syntax	Read_All_Input_Discretes_RTD (int handle, usint *readbuf)	
Input Parameters	handle	The handle designated by Init_Card_RTx
Output Parameters	readbuf	Each bit represents value of an input Discrete for a channel:
		bit 0 = channel 0
		bit 1 = channel 1
		bit 2 = channel 2
		bit 3 = channel 3
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Read_Input_Discrete_RTD

Description	Read_Input_Discrete_RTD reads a specific input channel.	
Syntax	Read_Input_Discrete_RTD (int handle, uint inchannel, uint *value)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	inchannel	The input channel: a value 0 – 3
Output Parameters	value	0 low 1 high
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Read_Output_Discrete_RTD

Description	Read_Output_Discrete_RTD reads output for a specific channel.	
Syntax	Read_Output_Discrete_RTD (int handle, uint outchannel, uint *value)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	outchannel	The output channel: a value 0 – 3
Output Parameters	value	0 low 1 high
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Read_Pending_RTD

Description	Read_Pending_RTD reads the pending value for a specific channel, from the Interrupt Pending Register	
Syntax	Read_Pending_RTD (int handle, uint inchannel, uint *pending_val)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	inchannel	The input channel: a value 0 – 3
Output Parameters	pending_val	0 input channel was not triggered
		1 input channel was triggered
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Read_Pending_Register_RTD

Description	Read_Pending_Register_RTD reads the Pending Interrupt Register.	
Syntax	Read_Pending_Register_RTD (int handle, uint *pending_reg)	
Input Parameters	handle	The handle designated by Init_Card_RTx
Output Parameters	pending_reg	For each bit (0 – 3)
		0 corresponding input channel was not triggered
		1 corresponding input channel was triggered
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Reset_RTD

Description	Reset_RTD resets the Discrete I/O channel to its default values. Discrete I/O is stopped.	
Syntax	Reset_RTD (int handle)	
Input Parameters	handle	The handle designated by Init_Card_RTx
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Reset_Pending_RTD

Description	Reset_Pending_RTD resets the bit of the Pending Register corresponding to the specific input channel.	
Syntax	Read_Input_Discrete_RTD (int handle, usint inchannel)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	inchannel	The input channel: a value 0 – 3
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Reset_Pending_Register_RTD

Description	Reset_Pending_Register_RTD resets the specified bits of the Interrupt Pending Register.	
Syntax	Reset_Pending_Register_RTD (int handle, usint pending_reg)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	pending_reg	One or more of the following flags O'Red together (indicating which channels should be reset): RESET_CHAN_0 [1 H] RESET_CHAN_1 [2 H] RESET_CHAN_2 [4 H] RESET_CHAN_3 [8 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebaddischan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Set_Threshold_RTD

Description	Set_Threshold_RTD sets the threshold voltage range.	
Syntax	Set_Threshold_RTD (int handle, usint threshold)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	threshold	THRESH_TTL 0 – 5V (default) [1 H] THRESH_AV 0 – 32V [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	einval	If an illegal threshold was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Set_Trigger_RTD

Description	Set_Trigger_RTD sets triggering on/off and if the trigger/interrupt will be activated by a rising or a falling edge input for a specific channel.	
Syntax	Set_Trigger_RTD (int handle, usint inchannel, int triggerval)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	inchannel	The input channel: a value 0 – 3
	triggerval	TRIGGER_OFF no trigger [2 H] TRIGGER_FALLING trigger falling edge [1 H] TRIGGER_RISING trigger rising edge [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	eival	If an illegal trigger value was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Set_Trigger_Destination_RTD

Description	If a trigger occurs Set_Trigger_Destination_RTD sets whether or not an interrupt will occur.	
Syntax	Set_Trigger_Destination_RTD (int handle, usint dest)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	dest	DEST_INTERRUPT Sets an interrupt on trigger [1 H] DEST_NONE No interrupt on trigger [0 H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	eival	If an invalid value was specified as in input
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Set_Trigger_Mask_RTD

Description	Set_Trigger_Mask_RTD sets the triggering on/off for each input channel. It specifies which channel should be monitored for the activation of the interrupt line and or the external trigger.	
Syntax	Set_Trigger_Mask_RTD (int handle, uint mask)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	mask	For each input channel to trigger on, the corresponding bit should be set to 1: TRIG_CHAN_0 [1 H] TRIG_CHAN_1 [2 H] TRIG_CHAN_2 [4 H] TRIG_CHAN_3 [8 H] TRIG_ALL_CHANS [7FFF H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	eival	If an invalid value was specified as in input
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Set_Trigger_Value_RTD

Description	Set_Trigger_Value_RTD specifies for each input channel if the trigger/interrupt will be activated by a rising edge or a falling edge input. Rising edge is the default value.	
Syntax	Set_Trigger_Mask_RTD (int handle, uint value)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	value	One or more of these flags OR'ed together may be used to specify which channels should trigger on falling edge: CHAN_0_FALL [1 H] CHAN_1_FALL [2 H] CHAN_2_FALL [4 H] CHAN_3_FALL [8 H] ALL_CHANS_FALL [7FFF H]
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	einval	If an invalid value was specified as in input
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Start_Discrete_RTD

Description	Start_Discrete_RTD starts the Discrete input / output channels. All channels must be set up before they are started	
Syntax	Start_Discrete_RTD (int handle)	
Input Parameters	handle	The handle designated by Init_Card_RTx
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Stop_Discrete_RTD

Description	Stop_Discrete_RTD stops the Discrete input / output channels.	
Syntax	Stop_Discrete_RTD (int handle)	
Input Parameters	handle	The handle designated by Init_Card_RTx
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Write_Output_Discrete_RTD

Description	Write_Output_Discrete_RTD writes the output Discrete for a specific channel.	
Syntax	Write_Output_Discrete_RTD (int handle, uint outchannel, uint value)	
Input Parameters	handle	The handle designated by Init_Card_RTx
	outchannel	The output channel: a value 0 – 3
	value	0 low 1 high
Output Parameters	none	
Return Values	ebadhandle	If handle other than the one returned by Init_Card_RTx is used
	ebadchan	If an illegal channel was specified
	enodiscretes	If no module is present with both ARINC 429 and Discrete channels
	0	If successful

Appendix A Data Configuration Returned by Read Data and Load Message Functions

The data returned by Read_Next_Data_RT_x and Read_Next_Merge_Data_RT_x consists of 5-word blocks.

The data returned by Read_Next_Data_IRIG_RT_x and Read_Next_Merge_Data_IRIG_RT_x consists of 7-word blocks.

Each block has the following configuration:

For Non-IRIG B Time		For IRIG B Time	
Word 0	DATA WORD HI	Word 0	DATA WORD HI
Word 1	DATA WORD LO	Word 1	DATA WORD LO
Word 2	TIME TAG HI	Word 2	TIME TAG HI
Word 3	TIME TAG LO	Word 3	TIME TAG SECOND
Word 4	STATUS	Word 4	TIME TAG THIRD
			TIME TAG FOURTH
			STATUS

When not using IRIG B time, the Time Tag precision is 10 μ sec. When using IRIG B time, the Time Tag precision is 1 μ sec. The IRIG B Time Tag is described on page A-2.

The Status Word is a combination of the following flags:

WORD_RECEIVED	Indicates that a Data Word has been written
HI_BIT_CNT_ERR	Hi bit count error
LO_BIT_CNT_ERR	Lo bit count error
PARITY_ERR	Parity error
INVALID_CODING_ERR	Bit level decoding error
GAP_TIME_ERR	Gap time error between words (less than 4 bit times)
VALID_WORD	Received ARINC word was valid in all respects

In Merge Mode, the Status Word contains the number of the receiving channel in bits 08 – 11 (where the LSB is bit 08).

The data returned by the function Read_Lkup_Data_RT_x consists of a single 6-word block when not using IRIG B time, or 8-word blocks when using IRIG B time, where each block has the following configuration:

For Non-IRIG B Time		For IRIG B Time	
Word 0	DATA WORD HI	Word 0	DATA WORD HI
Word 1	DATA WORD LO	Word 1	DATA WORD LO
Word 2	TIME TAG HI	Word 2	TIME TAG HI
Word 3	TIME TAG LO	Word 3	TIME TAG 2nd
Word 4	ERROR COUNT	Word 4	TIME TAG 3rd
Word 5	STATUS	Word 5	TIME TAG 4th
		Word 6	ERROR COUNT
		Word 7	STATUS

When not using IRIG B time, the Time Tag precision is 10 μ sec. When using IRIG B time, the Time Tag precision is 1 μ sec. The error count is per label.

The following figure shows the IRIG B Time Tag.




Figure A-1 IRIG B Time Tag

The Status Word is a combination of the flags:

WORD_RECEIVED	Indicates that a Data Word has been written
HI_BIT_CNT_ERR	Hi bit count error
LO_BIT_CNT_ERR	Lo bit count error
PARITY_ERR	Parity error
INVALID_CODING_ERR	Bit level decoding error
GAP_TIME_ERR	Gap time error between words (less than 4 bit times)
VALID_WORD	Received ARINC word was valid in all respects

Figure A-2 illustrates the memory configuration of the 32-bit data read or loaded using:

Output – Read	Read_Next_Data_RT _x
	Read_Next_Merge_Data_RT _x
	Read_Lkup_Data_RT _x
Input – Load	Load_Message_RT _x

The numbers shown represent the ARINC bit locations within the 32-bit word.




Figure A-2 Configuration in Memory of 32-bit Data Memory

Note: The bits 09 through 32 are ordered from LSB to MSB (the opposite from the Label field that is organized from MSB to LSB). For this reason, the Hi-Word is followed by the Lo-Word in the data block: the Label and the ARINC field 32 through 25 in the Hi-Word and bits 24 through 09 in the Lo-Word.

Appendix B *429RTx & Discrete Software Tools Library*

Appendix B includes a list of the files in the Excalibur *429RTx & Discrete Software Tools* needed to write user-defined applications. The files are divided into three categories:

Source code and Header files for the *429RTx & Discrete Software Tools* functions. Header files should be included in application programs as needed.

File Extension	Description
*.c	source code
*.h	header file

DLL and associated *.lib files

File Extension	Description
*MS.dll	Microsoft compiled DLL
*MS.dll	Index file used to create applications using Microsoft DLL functions

Demo Programs are examples of programs using *429RTx & Discrete Software Tools*. They can be used as a basis for user-defined programs. Demo programs include the following types of files.

File Extension	Description
*.c, *.h	Demo source code
*.exe	Demo executable files
*.sln *.suo	Microsoft project solution files

	File Name	Description
Source Code Files	api_rtd.c	Functions for writing test applications for Discrete channels
	deviceio.c	Functions relating to resources such as memory and interrupts – these functions act on kernel drivers
	deviceio_rtx.c	Functions for interaction with kernel driver for Windows operating systems
	EXC4000.c	For <i>M4K429RTx/M8K429RT5</i> modules on PCI carrier boards – functions for extracting information associated with the carrier board.
	EXCv4000.c	For <i>M4K429RTx/M8K429RT5</i> modules on VME/XVI carrier boards – functions for extracting information associated with the carrier board.
	initcard.c	Initialization and Release module/card functions
	Libdbg.c	Functions to display error messages
	Libgen.c	General functions to setup RTx modules/ cards
	Libmer.c	Functions to setup and operate ARINC receive channels in Merge Storage Mode
	Librcv.c	Functions to setup and operate ARINC receive channels
	Libtx.c	Functions to setup and operate ARINC transmit channels
Source Header files	deviceio.h	Header file for interaction with kernel driver
	error_devio.h	Header file containing error codes for the Excalibur kernel drivers
	error_rtx.h	Header file containing error message codes
	exc4000.h	For <i>M4K429RTx/M8K429RT5</i> on PCI carrier boards – Header file containing prototypes for functions associated with the carrier board

	File Name	Description
	EXCv4000.h	For <i>M4K429RTx/M8K429RT5</i> on VME/VXI carrier boards – Header file containing prototypes for functions associated with the carrier board.
	excdef.h	Header file to differentiate between different Excalibur products
	Excsysio.h	Header file which defines control codes in kernel drivers and defines strings for module/card names for use in Init_Module_RTx/Init_Card_RTx calls to kernel drivers
	Flags_rtx.h	Header file containing flags for <i>RTx</i> , for applications
	rtxIncl.h	Header file, include file for the <i>RTx</i> DLL code, not to include for applications
	Instance_rtx.h	Header file for global module structure
	proto_rtx.h	Header file, prototypes of all functions. This will include all the header files needed for applications
Demo Programs	demo_async.exe	Async loopback demo
	demo_data_only_mode.exe	Loopback demo using Data Only Storage Mode
	demo_dio.exe	Demonstrates Discrete input /output channels
	demo_dio_int.exe	Demonstrates Discrete input /output channels with interrupts
	demo_enhanced_freq.exe	Demo using the Enhanced Frequency function Load_FrequencyMessage_RTx
	demo_FIFO.exe	FIFO Mode demo
	demo_filter.exe	Filter Table demo
	demo_information_429.exe	Demo that returns 429RTx board type information
	demo_int.exe	Interrupt demo using a loopback (test) cable
	demo_IRIG_ttag.exe	Loopback with IRIG Time Tag demo

File Name	Description
demo_IRIG_ttag_merge.exe	Loopback with IRIG Time Tag Merge Mode demo
demo_lookup.exe	Look-up Table Storage Mode demo
demo_loopback.exe	Loopback demo
demo_merge.exe	Merge Mode demo
demo_parse_429_data.exe	Demo parsing a 32-bit ARINC 429 Data Word
demo_RX_only.exe	Receive (Monitor) demo
demo_skip.exe	Demo with skipped messages
demo_translate.exe	Demo that the translation function
demo_translate_other_side.exe	Demo to run opposite demo_translate
demo_ttagxmt.exe	Data Reconstructor demo
demo_TX_only.exe	Transmit demo
DLL and LIB files	The DLL and LIB files have the same filename except for the file extension. The filename is: Exc429RtxMs A board level DLL accompanies the module for each of the boards and cards. Depending on the board, the names of the files are:
Carrier Board	DLL Name
VME and VXI	ExcV4000Ms.dll
All Other Boards/Cards	Exc4000Ms.dll

Appendix C Code Index

The *429RTx & Discrete Software Tools* is a set of C language functions designed to aid users of the *429RTx[D]* to write test programs. Below is an alphabetical listing of all the functions and the name of the *Software Tools* file which contains its programming code.

Driver Functions	Code File Name
Add_Translation_Entry_RT _x ^a	librcv.c
Add_TTAG_Data_RT _x ^a	libxmtTtag.c
Allocate_MAX_Transmit_FIFOs_RT _x ^a	libtx.c
Allocate_Message_RT _x	libtx.c
Allocate_Transmit_FIFO_RT _x	libtx.c
Alter_Translation_Entry_RT _x ^a	librcv.c
Clear_Merge_Word_Count_RT _x	libmer.c
Clear_Rcv_Word_Count_RT _x	librcv.c
Clear_Rcvd_Error_Cnt_RT _x	librcv.c
Enable_Filter_Table_RT _x	librcv.c
Enable_Lkup_Table_RT _x	librcv.c
Enable_Merge_Filter_Table_RT _x	libmer.c
Enable_Translation_Table_RT _x	librcv.c
Enter_Lkup_Entry_RT _x	librcv.c
Get_DmaAvailable_RT _x	initcard.c
Get_Error_String_RT _x	libdbg.c
Get_HWid_RTD	api_rtd.c
Get_Interrupt_Count_RT _x	deviceio_rtx.c
Get_Time_Tag_RT _x	libgen.c
Get_UseDmalfAvailable_RT _x	initcard.c
Init_Module_RT _x	initcard.c
InitializeInterrupt_RT _x	deviceio_rtx.c
Load_FrequencyMessage_RT _x	libtx.c
Load_Message_RT _x	libtx.c
Load_Transmit_FIFO_RT _x ^a	libtx.c

Driver Functions	Code File Name
Map_Label_To_Translation_Entry_RTxa	librcv.c
Read_All_Input_Discretes_RTD	api_rtd.c
Read_Board_Intr_Status_RTxa	libgen.c
Read_Board_Status_RTxa	libgen.c
Read_Chan_Config_Register_RTxa	libgen.c
Read_Chan_Config_Stat_RTxa	libgen.c
Read_Channel_Status_RTxa	librcv.c
Read_Global_Start_RTxa	libgen.c
Read_Input_Discrete_RTD	api_rtd.c
Read_HwRevision_RTxa	libgen.c
Read_Lkup_Current_Lbl_RTxa	librcv.c
Read_Lkup_Data_RTxa	librcv.c
Read_Merge_Error_Cnt_RTxa	libmer.c
Read_Merge_Rcvd_Word_Cnt_RTxa	libmer.c
Read_Merge_Status_RTxa	libmer.c
Read_Next_Data_IRIG_RTxa	librcv.c
Read_Next_Data_RTxa	librcv.c
Read_Next_Merge_Data_IRIG_RTxa	libmer.c
Read_Next_Merge_Data_RTxa	libmer.c
Read_Number_Of_Channels_RTxa	libgen.c
Read_Output_Discrete_RTD	api_rtd.c
Read_Pending_Register_RTD	api_rtd.c
Read_Pending_RTD	api_rtd.c
Read_Rcvd_Data_Word_Cnt_RTxa	librcv.c
Read_Rcvd_Error_Cnt_RTxa	librcv.c
Read_Revision_RTxa	libgen.c
Read_SerialNumber_RTxa	libgen.c
Read_Tx_Loop_Cnt_RTxa	libtx.c
Read_Tx_Total_Words_Sent_RTxa	libtx.c

Driver Functions	Code File Name
Readback_Filter_Entry_RT _x	librcv.c
Release_Module_RT _x	initcard.c
Reset_Channel_Configuration_RT _x	libgen.c
Reset_Pending_Register_RT _D	api_rtd.c
Reset_Pending_RT _D	api_rtd.c
Reset_RT _D	api_rtd.c
Reset_Ttag_RT _x	libgen.c
Set_Filter_Entry_RT _x	librcv.c
Set_Global_Storage_Mode_RT _x	libgen.c
Set_Interrupt_Cond_RT _x	librcv.c
Set_IRIG_Timetag_Mode_RT _x	libgen.c
Set_Label_Trigger_RT _x	librcv.c
Set_Merge_Interval_Trig_RT _x	libmer.c
Set_Merge_Intr_Cond_RT _x	libmer.c
Set_Merge_Label_Trigger_RT _x	libmer.c
Set_Merge_Trig_Cond_RT _x	libmer.c
Set_Merge_Word_Cnt_Trig_RT _x	libmer.c
Set_Prog_Bit_Rate_RT _x	libgen.c
Set_Rcv_Interval_Trig_RT _x	librcv.c
Set_Rcv_Word_Cnt_Trig_RT _x	librcv.c
Set_Rcvd_Error_Cnt_RT _x	librcv.c
Set_Skip_Message_RT _x	libtx.c
Set_Threshold_RT _D	api_rtd.c
Set_Transmit_FIFO_Size_RT _x [⌘]	libtx.c
Set_Transmit_Loop_Counter_RT _x [⌘]	libtx.c
Set_Transmit_Message_Once_RT _x	libtx.c
Set_Trigger_Cond_RT _x	librcv.c
Set_Trigger_Cond_RT _x [⌘]	librcv.c
Set_Trigger_Destination_RT _D	api_rtd.c

Driver Functions	Code File Name
Set_Trigger_Mask_RTD	api_rtd.c
Set_Trigger_RTD	api_rtd.c
Set_Trigger_Value_RTD	api_rtd.c
Set_UseDmalfAvailable_RTx	libtx.c
Setup_Frame_RTx	libtx.c
Setup_Merge_Mode_RTx	libmer.c
Setup_Receive_Channel_RTx	librcv.c
Setup_Transmit_Channel_RTx	libtx.c
Setup_Ttag_Mode_RTx ^a	libxmtTtag.c
Start_Channel_RTx	libgen.c
Start_Discrete_RTD	api_rtd.c
Start_Selected_Channels_RTx	libgen.c
Stop_Channel_RTx	libgen.c
Stop_Discrete_RTD	api_rtd.c
Stop_Selected_Channels_RTx	libgen.c
Wait_For_Interrupt_RTx	deviceio_rtx.c
Wait_For_Multiple_Interrupts_RTx	deviceio_rtx.c
Write_Output_Discrete_RTD	api_rtd.c

Appendix D Error Messages

All functions in *429RTx & Discrete Software Tools* are written as C functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_RTx` function. Below is a list of all *Software Tools* error messages, the negative value of each, and an explanation of the error.

Error Code	Value	Explanation
<code>EINVAL</code>	-2	Illegal value used as an input
<code>sim_no_mem</code>	-5	Not enough memory available for simulation
<code>ewrngmodule</code>	-27	Module specified on carrier board is not an RTx module
<code>enomodule</code>	-28	No module is present at the specified location
<code>ebadhandle</code>	-33	Invalid handle specified; should be value returned by <code>Init_[Module/Card]_RTx</code>
<code>eboardtoomany</code>	-36	Too many modules initialized
<code>noirqset</code>	-53	No interrupt allocated.
<code>sixchancard</code>	-400	Tried to enable a channel number greater than 5 on a six channel card. The card is not initialized.
<code>sixtransmitchancard</code>	-401	Only six 429 transmit channels available on card
<code>init_failed</code>	-402	Failed to initialize the module/card
<code>param_Read_Chan_Config_Stat</code>	-403	Bad parameter in <code>Read_Chan_Config_Stat_RTx</code>
<code>param_Set_Global_Storage_Mode</code>	-404	Bad parameter in <code>Set_Global_Storage_Mode_RTx</code>
<code>param_Start_Channel</code>	-405	Bad parameter in <code>Start_Channel_RTx</code>
<code>param_Stop_Channel</code>	-406	Bad parameter in <code>Stop_Channel_RTx</code>
<code>param_Set_Prog_Bit_Rate</code>	-407	Bad parameter in <code>Set_Prog_Bit_Rate_RTx</code>
<code>param_Setup_Receive_Channel</code>	-408	Bad parameter in <code>Setup_Receive_Channel_RTx</code>
<code>bad_rcv_chan</code>	-409	Not a receive channel
<code>mem_Setup_Receive_Channel</code>	-410	Not enough memory to set up a receive channel
<code>param_Enable_Lkup_Table</code>	-411	Bad parameter in <code>Enable_Lkup_Table_RTx</code>
<code>mem_Enable_Lkup_Table</code>	-412	Not enough memory
<code>mode_Enable_Lkup_Table</code>	-413	Bad receive mode
<code>param_Enter_Lkup_Entry</code>	-414	Bad parameter in <code>Enter_Lkup_Entry_RTx</code>

Error Code	Value	Explanation
mem_Enter_Lkup_Entry	-415	Not enough memory for a new Look-up Table entry
param_Read_Lkup_Data	-416	Bad parameter in Read_Lkup_Data_RTx
param_Enable_Filter_Table	-418	Bad parameter in Enable_Filter_Table_RTx
mem_Enable_Filter_Table	-419	Not enough memory to enable a Filter Table
param_Read_Rcvd_Data_Word_Cnt	-420	Bad parameter in Read_Rcvd_Data_Word_Cnt_RTx
param_Read_Rcvd_Error_Cnt	-421	Bad parameter in Read_Rcvd_Error_Cnt_RTx
param_Read_Lkup_Current_Lbl	-422	Bad parameter in Read_Lkup_Current_Lbl_RTx
param_Read_Channel_Status	-423	Bad parameter in Read_Channel_Status_RTx
param_Set_Label_Trigger	-424	Bad parameter in Set_Label_Trigger_RTx
param_Set_Rcv_Interval_Trig	-425	Bad parameter in Set_Rcv_Interval_Trig_RTx
param_Set_Rcv_Word_Cnt_Trig	-426	Bad parameter in Set_Rcv_Word_Cnt_Trig_RTx
bad_chan	-427	An invalid channel was specified
bad_param	-428	An invalid parameter was specified
fivechanmod	-429	Tried to enable a channel number greater than 4 on a five channel RTx module. The module is not initialized.
no_filter_table	-430	No Filter Table is defined
esetuptxchan	-431	Illegal call to Allocate_Message_RTx or Load_Message_RTx before Setup_Transmit_Channel_RTx
ewrngcard	-432	If no module is present with both ARINC 429 and Discrete channels
eboardnotstopped	-433	Cannot change communication parameters
param_Set_Interrupt_Cond	-434	Bad parameter in Set_Interrupt_Cond_RTx
param_Set_Trigger_Cond	-435	Bad parameter in Set_Trigger_Cond_RTx
param_Setup_Transmit_Channel	-436	Bad parameter in Setup_Transmit_Channel_RTx
mem_Setup_Transmit_Channel	-437	Not enough memory to set up a transmit channel
bad_tx_chan	-438	Not a transmit channel
param_Load_Message	-439	Bad parameter in Load_Message_RTx
msg_num_Load_Message	-440	Bad message number

Error Code	Value	Explanation
lkup_data_invalid	-441	Look-up Table data is invalid
mem_Setup_Merge_Mode	-442	Not enough memory
mem_Enable_Merge_Filter_Table	-443	Not enough memory
param_Read_Tx_Loop_Cnt	-444	Bad parameter in Read_Tx_Loop_Cnt_RTx
param_Read_Next_Data	-445	Bad parameter in Read_Next_Data_RTx
param_Allocate_Message	-446	Bad parameter in Allocate_Message_RTx
mem_Allocate_Message	-447	Not enough memory to allocate the message
msg_Allocate_Message	-448	Too many calls to Allocate_Message_RTx; the number of messages cannot exceed <code>max_messages</code> in <code>Setup_Transmit_Channel_RTx</code>
param_Clear_Rcv_Word_Count	-449	Bad parameter in Clear_Rcv_Word_Count_RTx
param_Read_Tx_Total_Words_Sent	-450	Bad parameter in <code>Read_Tx_Total_Words_Sent_RTx</code>
param_Enable_Translation_Table	-451	<code>Enable_Translation_Table_RTx</code> was not called for this channel
param_Skip_Message	-452	An invalid channel was specified in <code>Set_Skip_Message_RTx</code>
msg_num_Skip_Message	-453	If an invalid message number was specified in <code>Set_Skip_Message_RTx</code>
init_failed_1	-461	Failed to initialize the module/card
init_failed_2	-462	Failed to initialize the module/card
init_failed_3	-463	Failed to initialize the module/card
no_extended_time_support	-464	Extended Time is enabled on the channel but not supported by the firmware
tenchanmod	-465	Tried to enable a channel number greater than 9 on a ten channel RTx module. The module is not initialized.
param_Set_IRIG_Timetag_Mode	-467	Illegal mode selected in <code>Set_IRIG_Timetag_Mode</code>
param_Read_Next_Data_IRIG	-468	Cannot use <code>Read_Next_Data_IRIG_RTx</code> in <code>DATA_ONLY_MODE</code>
ewrongmode	-469	Incorrect mode for using this function
eNolrigSupportModule	-470	Module is not a Nios-based processor, so it cannot use IRIG-based functions

Error Code	Value	Explanation
no_translation_table	-472	Attempt to map to a translation entry on a channel with no translation table
mem_Enable_Translation_Table	-473	Insufficient memory for a translation table
mem_Enable_Translation_Entry	-474	Insufficient memory for an new translation table entry or there are more than five translation operations defined in the translation entry
efeature_not_supported_RTX	-475	Feature is not supported on this module
param_Load_Message1	-481	Bad parameter in Load_Message_RTx or Load_FrequencyMessage_RTx; word_cnt is greater than 255
param_Load_Message2	-482	Bad parameter in Load_Message_RTx or Load_FrequencyMessage_RTx; interword_dly is greater than 255
param_Load_Message3	-483	Bad parameter in Load_Message_RTx or Load_FrequencyMessage_RTx; Setup_Transmit_Channel_RTx specifies EXTENDED_TIME_ENABLE and intermsg_rate or frequency is greater than 1310 or less than 1
param_Load_Message4	-484	Bad parameter in Load_Message_RTx or Load_FrequencyMessage_RTx; Setup_Transmit_Channel_RTx did not specify EXTENDED_TIME_ENABLE and intermsg_rate or frequency is greater than 65535 (FFFF H) or less than 0
param_Load_Message5	-485	Bad parameter in Load_Message_RTx or Load_FrequencyMessage_RTx; there is no space left on the module for word_cnt words
eenhancedfrequencynotsupported	-487	If the firmware on this module does not support the Enhanced Frequency function Load_FrequencyMessage_RTx
enotdatarate	-488	If Setup_Transmit_Channel_RTx did not set this channel to be in DATA_RATE_MODE
For Discrete Channels		
ebaddischan	-500	Tried to set channel to illegal value
enodiscretes	-501	If no module is present with both ARINC 429 and Discrete channels

Error Code	Value	Explanation
For all Boards EXCEPT VME/VXI Boards		
eopenkernel	-1001	Error opening kernel device; check ExcConfig settings
ekernelcantmap	-1002	Error mapping memory
ereleventhandle	-1003	Error releasing the event handle
egetintcount	-1004	Error getting interrupt count
egetchintcount	-1005	Error getting channel interrupt count
egetintchannels	-1006	Error getting interrupt channels
ewriteiobyte	-1007	Error writing I/O memory
ereadiobyte	-1008	Error reading I/O memory
egeteventhand1	-1009	Error getting event handle (in first stage)
egeteventhand2	-1010	Error getting event handle (in second stage)
eopenscmant	-1011	Error opening Service Control Manager (in startkerneldriver)
eopenservicet	-1012	Error opening kernel service (in startkerneldriver)
estartservice	-1013	Error starting kernel service (in startkerneldriver)
eopenscmanp	-1014	Error opening Service Control Manager (in stopkerneldriver)
eopenservicep	-1015	Error opening kernel service (in stopkerneldriver)
econtrolservice	-1016	Error in control service (in stopkerneldriver)
eunmapmem	-1017	Error unmapping memory
egetirq	-1018	Error getting IRQ number
eallocresources	-1019	Error allocating resources; see Installation Instructions.pdf for details on resource allocation problems
egetramsize	-1020	Error getting RAM size
ekernelwriteattrib	-1021	Error writing attribute memory
ekernelreadattrib	-1022	Error reading attribute memory
ekernelfrontdesk	-1023	Error opening kernel device; check ExcConfig set up
ekernelOsccheck	-1024	Error determining operating system
ekernelfrontdeskload	-1025	Error loading frontdesk.dll

Error Code	Value	Explanation
ekerneliswin2000compatible	-1026	Error determining Windows 2000 compatibility
ekernelbankramsize	-1027	Error determining memory size
ekernelgetcardtype	-1028	Error getting card type
emodnum	-1029	Invalid module number specified
regnotset	-1030	Board not configured; reboot after ExcConfig is run and board is in slot
ekernelbankphysaddr	-1031	Error getting physical memory address
ekernelclosedevice	-1032	Error closing kernel device
ekerneldevicenotopen	-1034	Error returned by kernel: device not open
ekernelinitmodule	-1035	Error initializing kernel
ekernelbadparam	-1036	Error returned by kernel: bad input parameter
ekernelbadpointer	-1037	Error returned by kernel: invalid pointer to output buffer
ekerneltimeout	-1038	Timeout expired before interrupt occurred
ekernelnotwin2000	-1039	Error returned by kernel: operating system is not Windows 2000 compatible
erequestnotification	-1040	Error requesting interrupt notification
ekernelnot4000card	-1041	Error returned by kernel: designated board is not EXC-4000/8000 family
enotimersirig	-1042	Timers and IrigB are not supported on this version of EXC-4000/8000 family board
eclocksource	-1059	Invalid clock source specified
eparmglobalreset	-1062	Illegal parameter used for globalreset_flag in the StartTimer_4000 function
etimernotrunning	-1063	Timer not running when function was called; did nothing
etimerrunning	-1064	Timer already running; did nothing
eparmreload	-1065	Illegal parameter used for reload_flag in StartTimer_4000
eparminterrupt	-1066	Illegal parameter used for interrupt_flag in StartTimer_4000
ebaddevhandle	-1067	Invalid handle specified; use value returned by Init_Timers_4000

Error Code	Value	Explanation
edevtoomany	-1068	Init_Timers_4000 called for too many boards
einvalidOS	-1069	Invalid operating system
enotforunet	-1089	Function invalid for UNET
For VME/VXI Boards Only		
eviclosedev	-1050	Error closing the device
evicloserm	-1051	Error closing the default RM
eopendefaultrm	-1052	Error opening the default RM
eviopen	-1053	Error opening VISA
evimapaddress	-1054	Error mapping address
evicommand	-1055	Error in VISA command
einstallhandler	-1056	Error installing VISA handler
eenableevent	-1057	Error enabling VISA event
euninstallhandler	-1058	Error uninstalling VISA handler
edevnum	-1060	Specified device number greater than 255
einstr	-1061	Error initializing module

Function Index

A

Add_Translation_Entry_RTx 3-8
Add_TTAG_Data_RTx 4-25
Allocate_MAX_Transmit_FIFOs_RTx 4-21
Allocate_Message_RTx 4-6
Allocate_Transmit_FIFO_RTx 4-22
Alter_Translation_Entry_RTx 3-10

C

Clear_Merge_Word_Count_RTx 3-25
Clear_Rcv_Word_Count_RTx 3-14
Clear_Rcvd_Error_Cnt_RTx 3-14

E

Enable_Filter_Table_RTx 3-15
Enable_Lkup_Table_RTx 3-34
Enable_Merge_Filter_Table_RTx 3-25
Enable_Translation_Table_RTx 3-12
Enter_Lkup_Entry_RTx 3-35

G

Get_DmaAvailable_RTx 2-2
Get_Error_String_RTx 2-2
Get_HWid_RTD 5-2
Get_Interrupt_Count_RTx 2-20
Get_Time_Tag_RTx 2-3
Get_UseDmalfAvailable_RTx 2-3

I

Init_Module_RTx 2-4
InitializeInterrupt_RTx 2-20

L

Load_FrequencyMessage_RTx 4-7
Load_Message_RTx 4-9
Load_Transmit_FIFO_RTx 4-23

M

Map_Label_To_Translation_Entry_RTx 3-13

R

Read_All_Input_Discretes_RTD 5-2
Read_Board_Intr_Status_RTx 2-7
Read_Board_Status_RTx 2-7
Read_Chan_Config_Register_RTx 2-8
Read_Chan_Config_Stat_RTx 2-9
Read_Channel_Status_RTx 3-16, 4-11
Read_Global_Start_RTx 2-9
Read_HwRevision_RTx 2-10
Read_Input_Discrete_RTD 5-3
Read_Lkup_Current_Lbl_RTx 3-35
Read_Lkup_Data_RTx 3-36
Read_Merge_Error_Cnt_RTx 3-26
Read_Merge_Rcvd_Word_Cnt_RTx 3-26
Read_Merge_Status_RTx 3-27
Read_Next_Data_IRIG_RTx 3-17
Read_Next_Data_RTx 3-18
Read_Next_Merge_Data_IRIG_RTx 3-28
Read_Next_Merge_Data_RTx 3-29
Read_Number_Of_Channels_RTx 2-10
Read_Output_Discrete_RTD 5-3

Read_Pending_Register_RTD 5-4
Read_Pending_RTD 5-4
Read_Rcvd_Data_Word_Cnt_RTx 3-19
Read_Rcvd_Error_Cnt_RTx 3-19
Read_Revision_RTx 2-10
Read_SerialNumber_RTx 2-11
Read_Tx_Loop_Cnt_RTx 4-12
Read_Tx_Total_Words_Sent_RTx 4-12
Readback_Filter_Entry_RTx 3-20
Release_Module_RTx 2-11
Reset_Channel_Configuration_RTx 2-12
Reset_Pending_Register_RTD 5-6
Reset_Pending_RTD 5-5
Reset_RTD 5-5
Reset_Ttag_RTx 2-13

S

Set_Filter_Entry_RTx 3-20
Set_Global_Storage_Mode_RTx 3-5
Set_Interrupt_Cond_RTx 3-21, 4-13
Set_IRIG_Timetag_Mode_RTx 2-13
Set_Label_Trigger_RTx 3-22
Set_Merge_Interval_Trig_RTx 3-30
Set_Merge_Intr_Cond_RTx 3-30
Set_Merge_Label_Trigger_RTx 3-31
Set_Merge_Trig_Cond_RTx 3-31
Set_Merge_Word_Cnt_Trig_RTx 3-32
Set_Prog_Bit_Rate_RTx 2-14
Set_Rcv_Interval_Trig_RTx 3-22
Set_Rcv_Word_Cnt_Trig_RTx 3-23
Set_Rcvd_Error_Cnt_RTx 3-23
Set_Skip_Message_RTx 4-14
Set_Threshold_RTD 5-6
Set_Transmit_FIFO_Size_RTx 4-24
Set_Transmit_Loop_Counter_RTx 4-15
Set_Transmit_Message_Once_RTx 4-16
Set_Trigger_Cond_RTx 3-24, 4-17
Set_Trigger_Destination_RTD 5-7
Set_Trigger_Mask_RTD 5-8
Set_Trigger_RTD 5-7
Set_Trigger_Value_RTD 5-9
Set_UseDmalfAvailable_RTx 2-15
Setup_Frame_RTx 4-18
Setup_Merge_Mode_RTx 3-33
Setup_Receive_Channel_RTx 3-6
Setup_Transmit_Channel_RTx 4-19
Setup_Ttag_Mode_RTx 4-26
Start_Channel_RTx 2-17
Start_Discrete_RTD 5-9
Start_Selected_Channels_RTx 2-16
Stop_Channel_RTx 2-17
Stop_Discrete_RTD 5-10
Stop_Selected_Channels_RTx 2-18

W

Wait_For_Interrupt_RTx 2-21
Wait_For_Multiple_Interrupts_RTx 2-22
Write_Output_Discrete_RTD 5-10

The information contained in this document is believed to be accurate. However, no responsibility is assumed by Excalibur Systems, Inc. for its use and no license or rights are granted by implication or otherwise in connection therewith. Specifications are subject to change without notice.

March 2025, Rev B-3